



## Parts List for FS9099 Type 1

Item Number	Part Number	Description	Qty Required
1	498796-00	KEYLESS CHUCK	1
2	149518-01	SCREW	1
866	486988-01	BATTERY	1
871	418337-18	CHARGER	1