



Parts List for G720-AR Type 1

Item Number	Part Number	Description	Qty Required
1	5140003-59	SLEEVE	1
2	5140003-60	BALL BEARING	1
3	5140003-61	ARMATURE	1
4	5140003-64	RET. RING	1
5	5140003-65	CAP BEARING	1
6	5140003-66	BALL BEARING	1
7	5140003-67	LOCK PIN	1
8	5140003-68	SPRING	1
9	5140003-69	RET. RING	1
10	5140003-70	SCREW	4
11	5140003-71	GEAR CASE	1
12	5140003-72	NEEDLE BEARING	1
13	5140003-73	RET RING	1
14	5140003-74	SPRING RING	1
15	5140003-75	GEAR	1
16	5140003-76	CAP BEARING	1
17	5140003-77	BALL BEARING	1
18	5140003-78	GEAR CASE COVER	1
19	5140003-79	SPRING WASHER	1
20	5140003-80	SCREW	4
21	5140003-81	GUARD	1
22	5140003-82	SCREW	1
23	5140002-29	CORD PROTECTOR	1
24	5140003-83	SCREW	1
25	5140002-31	CORD & PLUG	1
26	5140003-84	END CAP	1
27	5140003-85	RUBBER CASE	1

Parts List for G720-AR Type 1

Item Number	Part Number	Description	Qty Required
28	5140003-86	SCREW	1
29	5140002-35	BRUSH	2
30	5140002-37	BRUSH HOLDER	1
31	5140003-87	FIELD CASE	1
32	5140003-88	ROLLER	1
33	5140003-89	SCREW	2
34	5140003-90	HANDLE	1
35	5140003-91	PINION GEAR	1
36	5140003-92	SPRING WASHER	1
37	5140003-93	NUT	1
38	5140003-94	SCREW	3
39	5140003-95	FIELD	1
40	5140003-97	BAFFLE	1
43	5140002-48	CORD CLAMP	1
44	5140003-99	SCREW	2
45	5140002-54	SWITCH	1
46	5140004-01	CONDENSER	1
47	5140004-02	SWITCH ACTUATOR	1
48	5140004-03	SWITCH KNOB	1
49	5140004-04	SCREW	2
50	5140004-05	KEY	1
51	5140004-06	SPINDLE	1
52	5140002-52	FLANGE	1
53	5140002-53	CLAMP NUT	1
54	5140004-07	NUT	1
800	761995-01	GREASE, 6 OZ.	1