



GF28WW

3-1/2" Gas Wire-Weld Framing Nailer
Clavadora de clavos de armazón a gas para
soldadura de alambre de 3-1/2"
Agrafeuse pour treillis métallique à gaz, 88,9 mm

Parts List for GF28WW Type 0

Item Number	Part Number	Description	Qty Required
1	9R192101	HEX. SOCKET HD. BOLT	1
2	9R192102	TOP COVER	1
3	9R192103	FILTER	1
4	9R192104	MOTOR	1
5	9R192105	RUBBER WASHER	1
6	9R192106	ROLL PIN D2.5X25	1
7	9R192107	MOTOR MOUNT	1
8	9R192108	MOUNT SLEEVE	1
9	9R192109	SHAFT WASHER	1
10	9R192110	SPARK PLUG (A)	1
11	9R192111	MOTOR SPRING	1
12	9R192112	HEX. SOCKET HD. BOLT	4
13	9R192113	CYLINDER HEAD ASS'Y	1
14	9R192114	O-RING (I.D 59.92)	1
15	9R192115	NUT M4	2
16	9R192116	WASHER M4	2
17	9R192117	FAN	1
18	9R192118	HEX. SOCKET HD. BOLT	1
19	9R192119	CHAMBER HEAD	1
20	9R192120	GASKET (B)	1
21	9R192121	CHAMBER	1
22	9R192122	PLUNGER O-RING	1
23	9R192123	SHAFT RING	1
24	9R192124	BOLT WASHER M5	2
25	9R192125	SHAFT	1
26	9R192126	MACHINE SCREW M4X6	3
27	9R192217	WIRING PLATE	1

Parts List for GF28WW Type 0

Item Number	Part Number	Description	Qty Required
28	9R192127	ADAPTER	1
29	9R192128	HEX. SOCKET SET SCRE	1
30	9R192222	SHAFT COVER	1
31	9R192223	WASHER	1
32	9R192129	CHAMBER LOCK PLATE	1
33	9R192130	PIN (A)	1
34	9R192131	SWITCH PLATE	1
35	9R192132	O-RING (I.D. 66.27)	1
36	9R192133	RETAINING RING	1
37	9R192134	PISTON RING	2
38	9R192135	PISTON ASS'Y	1
39	9R192136	PISTON BUMPER	1
40	9R192137	CHAMBER STOP RUBBER	2
41	9R192138	CYLINDER ASS'Y	1
42	9R192139	SEAL LOCK HEX. SOCKE	1
43	9R192140	BUFFER COVER (A)	1
44	9R192141	LEAD VALVE	1
45	9R192221	SEAL LOCK SCREW M4X6	1
46	9R192142	MUFFLER	1
47	9R192143	BLADE GUIDE	1
48	9R192144	PLATE SLEEVE	1
49	9R192145	SIDE PLATE	1
50	9R192146	SPECIAL NUT M5	1
51	9R192147	NYLOCK HEX.SOCKET HD	1
52	9R192148	NOSE SLEEVE	1
53	9R192150	BELLEVILLE SPRING M4	3
54	9R192154	CYLINDER PLATE	1

Parts List for GF28WW Type 0

Item Number	Part Number	Description	Qty Required
55	9R192155	SEAL LOCK HEX. SOCKE	1
56	9R192152	PUSHING LEVER SPRING	1
57	9R192156	U-NUT M4	1
58	9R192139	SEAL LOCK HEX. SOCKE	2
59	9R192151	PUSHING LEVER ARM (C	1
60	9R192153	PUSHING LEVER CONNEC	1
61	9R192157	PUSHING LEVER ARM (D	1
62	9R192158	HEX. SOCKET HD. BOLT	1
63	9R192159	PUSHING STOPPER	1
65	9R192163	SCREW M5	1
66	9R192164	HOUSING (A)	1
67	9R192161	ADJUSTER BUSH (A)	1
68	9R192160	PUSHING LEVER(A)	1
69	9R192166	PROTECTOR(A)	4
70	9R192168	NYLON NUT M4	1
71	9R192169	HEX. SOCKET HD. BOLT	1
72	9R192170	SLEEVE	1
73	9R192171	TAPPING SCREW (W/FLA	2
74	9R192175	TAPPING SCREW (W/FLA	1
75	9R192176	SWITCH MOUNT	1
76	9R192177	SWITCH ARM	1
78	9R192172	HANDLE (B) ASS'Y	1
80	9R192178	PRISM (A)	1
81	9R192186	CHAMBER LOCK BAR	1
82	9R192185	TRIGGER SPRING (A)	1
83	9R192187	PIN D2.5	1
84	9R192188	TRIGGER INTERNAL WIR	1

Parts List for GF28WW Type 0

Item Number	Part Number	Description	Qty Required
85	9R192220	WIRING PLATE (B)	1
86	9R192219	TAPPING SCREW D3	2
87	9R192218	HOOK (B)	1
88	9R192189	NYLON NUT M5	1
89	9R192190	NAIL RAIL	1
90	9R192191	MAGAZINE PLATE	1
91	9R192184	TAPPING SCREW (W/FLA	2
92	9R192182	CONTROLLER	1
93	9R192180	WIRING COVER	1
94	9R192179	LOCK BAR SPRING	1
95	9R192181	FLAT HD. TAPPING SCR	1
96	9R192193	LATCH	1
97	9R192194	ROLL PIN D2X8	1
98	9R192195	SPRING D3.6	1
99	9R192196	CELL COVER	1
100	9R192214	TAPPING SCREW (W/FLA	1
102	9R192197	CELL RUBBER (A)	1
103	9R192202	SPRING	1
104	9R192203	SWITCH LEVER (B) ASS	1
105	9R192200	NAIL FEEDER (A)	1
106	9R192201	TENSION PLATE (C)	1
107	9R192205	LEVER STOPPER	1
108	9R192192	CELL LEVER (A)	1
109	9R192206	ROLL PIN D4X28	1
110	9R192224	SLEEVE	1
111	9R192207	SPRING	1
112	9R192339	NAIL FEEDER (B)	1

Parts List for GF28WW Type 0

Item Number	Part Number	Description	Qty Required
113	9R192209	RIBBON SPRING	1
114	9R192211	PUSHING LEVER STOPPE	1
115	9R192210	SPRING D8	1
116	9R192216	MAGAZINE GUARD	1
117	9R192215	HEX. SOCKET HD. BOLT	1
118	9R192212	HANDLE(A)	1
119	9R192398	FEEDER KNOB	1