



Parts List for GH600 Type 3

Item Number	Part Number	Description	Qty Required
1	90518524	HANDLE ASSEMBLY	1
4	000000-00	No Longer Available	1
5	90541381	SWITCH	1
6	244084-00	TRIGGER ASSY.	1
7	244053-00	SPRING, TRIGGER	1
8	330019-04	SCREW, PLASTITE	15
10	244075-00	LEAD WIRE ASSY	1
12	244077-01	AUX.HANDLE ASSY	1
13	000000-00	No Longer Available	1
14	610785-00	SCREW, MACHINE	1
18	244065-00	LATCH BUTTON	1
20	000000-00	No Longer Available	1
21	46629-01	CONNECTOR	2
22	AF-100	REPLACEMENT SPOOL	1
22	242885-01	SPOOL & LINE	1
23	243603-00	SPRING	1
27	243805-00	BLADE	1
28	681914-00	SCREW	2
29	598435-00SV	LEVER	1
30	244463-00	ADJUST BLOCK	1
31	243431-00	LABEL	1
33	244058-00	GUARD ASSY COMPLETE	1
800	000000-00	No Longer Available	1