



Parts List for GH750-B3LZ Type 2

Item Number	Part Number	Description	Qty Required
1	90517154	CLAMSHELL ASSY.	1
2	90551215	SWITCH,ON-OFF	1
3	90517189	TRIGGER	1
4	244053-00	SPRING, TRIGGER	1
5	90517157	TUBE ASSY	1
6	90532945	HANDLE ASSEMBLY	1
10	90517166	CLAMSHELL ASSY.	1
11	90527972-01	MOTOR ASSY	1
13	90522536	LEADWIRE ASSY.	1
14	821070	CORD CLAMP	1
15	90515608	EDGE BUTTON	1
16	580936-00	SPRING	1
17	90514753	GEAR ASSY.	1
18	90517168	GUARD ASSEMBLY	1
19	90527971	GUARD ASSEMBLY	1
20	90517174-01	EDGE GUIDE	1
21	90514754	SPOOL COVER	1
22	90517175	SPOOL & LINE	1
23	747329	SCREW	20
24	90515051	LINER	1
25	373158	SCREW	1
26	90518277	PLUG ASSY.	1
27	90553886	ID LABEL	1
28	90559261	NAME PLATE	1
30	90532945	HANDLE ASSEMBLY	1
31	90539049	KNOB ASSEMBLY	1
32	151710-00	SCREW	1

Parts List for GH750-B3LZ Type 2

Item Number	Part Number	Description	Qty Required
33	330015-02	NUT,HEX	1
34	243805-00	BLADE	1
35	681914-00	SCREW	2
36	90541507	WARNING LABEL	1
37	90548553	LEVER	1