



## Parts List for GL300-BR Type 2

| Item Number | Part Number | Description    | Qty Required |
|-------------|-------------|----------------|--------------|
| 1           | 5140018-69  | SPOOL CAP      | 1            |
| 2           | 5140018-70  | SPOOL HOLDER   | 1            |
| 3           | 5140018-71  | SPOOL          | 1            |
| 4           | 5140018-72  | SPRING         | 1            |
| 5           | 5140018-73  | SPOOL HOUSING  | 1            |
| 6           | 5140018-74  | GUARD          | 1            |
| 7           | 5140018-67  | MOTOR          | 1            |
| 8           | 5140018-75  | HOUSING,LH     | 1            |
| 9           | 5140076-29  | SCREW          | 1            |
| 10          | 5140076-30  | FLAT WASHER    | 1            |
| 11          | 5140076-31  | INSERT         | 1            |
| 12          | 5140076-32  | INSERT         | 1            |
| 13          | 5140018-82  | TERMINAL       | 1            |
| 14          | 5140076-33  | SLEEVE         | 1            |
| 15          | 5140018-86  | CONNECTOR ASSY | 1            |
| 16          | 5140018-87  | SWITCH         | 1            |
| 17          | 5140018-91  | CORD CLAMP     | 1            |
| 18          | 5140018-92  | CORD PROTECTOR | 1            |
| 19          | 5140018-88  | HOUSING,LEFT   | 1            |
| 20          | 5140018-89  | GEL PAD        | 1            |
| 21          | 5140018-98  | CORD SET       | 1            |
| 22          | 5140018-94  | ACTUATOR       | 1            |
| 23          | 5140018-93  | HOUSING, RH    | 1            |
| 24          | 5140076-34  | NUT            | 1            |
| 25          | 5140018-96  | HOUSING,RIGHT  | 1            |
| 26          | 5140076-35  | RUBBER BUMPER  | 1            |