



Parts List for GL350-B2C Type 1

Item Number	Part Number	Description	Qty Required
1	5140076-72	INSERT	1
2	5140076-73	INSERT	1
3	5140076-74	SPRING	3
4	5140076-75	CLIP	2
5	5140076-76	SCREW	6
6	5140076-77	TERMINAL,MALE	1
7	5140076-78	TERMINAL,MALE	1
8	5140076-79	EDGE BUTTON	1
10	5140076-80	SPRING	1
11	5140076-81	SCREW	18
12	5140076-82	MOTOR HOUSING	1
13	5140076-83	GUARD	1
14	5140076-84	SCREW	1
15	5140076-85	RUBBER PAD	2
16	5140076-86	BLADE	1
17	5140076-87	SPOOL COVER	1
18	5140076-88	OUTLET	2
19	5140076-89	LEVER	1
20	5140076-90	SPOOL	1
22	5140076-91	SPOOL HOUSING	1
23	5140076-92	EDGE GUIDE	1
24	5140076-93	MOTOR ASSY.	1
25	5140076-94	MOTOR HOUSING	1
26	5140077-00	HANDLE INSERT	1
27	5140076-98	HANDLE INSERT	1
28	5140076-95	SCREW	2
29	5140076-96	CABLE	1

Parts List for GL350-B2C Type 1

Item Number	Part Number	Description	Qty Required
30	5140076-97	TUBE	1
32	5140076-99	CLIP	1
34	5140077-01	HANDLE	1
35	5140077-02	HANDLE	1
36	5140077-03	HOUSING	1
37	5140077-04	CAPACITOR	1
38	5140077-05	CORD CLAMP	1
39	5140077-06	TERMINAL BLOCK	1
40	5140077-07	TRIGGER	1
42	5140077-08	SWITCH	1
43	5140077-09	SPRING	1
44	5140077-10	CORD PROTECTOR	1
45	5140077-11	HANDLE	1
46	5140077-12	CORDSET	1