



## Parts List for GL360-B2 Type 1

Item Number	Part Number	Description	Qty Required
2	90561370	GUARD ASSEMBLY	1
4	682378-02	CAP,BUMP	1
5	143684-04	SPOOL	1
6	682235-00	SPRING	1
7	90563260	SCREW	1
8	90566427	HANDLE ASSEMBLY	1
9	681914-00	SCREW	2
10	90566018	BLADE	1