


816



821



800

Parts List for GT5026-AR Type 1

Item Number	Part Number	Description	Qty Required
1	90531857	MOTOR & GEARCASE	1
2	90543630	GEAR ASSY.	1
3	90544207	BLADE ASSEMBLY	1
4	90527815-01	CLAMSHELL ASSY.	1
5	90554411	CORDSET	1
6	770235	CORD PROTECTOR	1
7	821070	CORD CLAMP	1
8	821057	PAN HEAD SCREW	4
9	373883	TERMINAL BLOCK	1
11	90532880	LEADWIRE	1
12	90545659	BRUSH & HOLDER ASSY	2
13	90532295	SPRING	1
14	90039466	TRIGGER	1
15	90533781	SWITCH ASSY.	1
17	90543632	ACTUATOR	1
18	90532861	ACTUATOR	1
19	90039468	PIVOT	1
20	90532771	HANDLE ASSY.	1
21	90528349	LOWER GUARD ASSY	1
22	90540971	SCREW	4
23	330045-16	SCREW,TAPTITE	2
24	90533548	NUT	2
25	330024-36	SCREW	4
26	90040523	BOTTOM PLATE	1
27	90524440	SUPPORT PLATE	1
28	747329	SCREW	9
29	574853-06	BEARING	2

Parts List for GT5026-AR Type 1

Item Number	Part Number	Description	Qty Required
30	90527993	GUARD	1
31	330024-34	MACHINE SCREW	2
32	90535282	SHEATH	1
800	870889-03	GREASE	1
816	90536337	BRAND LABEL	1
821	90555229	NAME PLATE	1