



861



866 867



871

## Parts List for HP1440K Type 1

Item Number	Part Number	Description	Qty Required
1	149518-01	SCREW	1
2	498796-00	KEYLESS CHUCK	1
3	148354-03	BIT CLIP	1
4	607918-41	SCREWDRIVER BIT	1
861	499124-07	KIT BOX	1
866	FSB14	BATTERY	1
867	5102026-00	BATTERY CAP	1
871	90500933	CHARGER	1
875	497641-05	LATCH	2