



Parts List for HP144K-BR Type 1

Item Number	Part Number	Description	Qty Required
2	5147442-01	CHARGER	1
4	311993-00	SCREW	3
5	486562-00	SCREW	1
6	498099-00	SCREW	2
7	5101824-22	GEARBOX	1
8	5100111-00	ACTUATOR FWR/REV	1
9	5104509-41	VSR SWITCH	1
10	5100153-01	SHIFTER WIRE	1
11	5100101-05	SHIFTER	1
12	5101812-00	COVER, TOP	1
14	5101813-02	CLAMSHELL SET	1
16	5103096-00	CHUCK SCREW	1
17	5103032-03	KEYLESS CHUCK	1
18	5102349-08	MOTOR & PINION	1
19	5101827-10	NAMEPLATE	1
20	5101892-00	BRAND LABEL	1
21	5100035-03	SPRING	2
866	499936-46	BATTERY	1