



Parts List for HPD1802 Type 3

Item Number	Part Number	Description	Qty Required
2	5101752-00	WASHER	1
3	419626-00	BEARING WASHER	1
4	311993-00	SCREW	3
5	486562-00	SCREW	1
6	330019-05	SCREW,PLASTITE	2
7	5100754-02	MOTOR & GEARBOX	1
8	5100117-00	SPRING	1
9	5100115-00	BIT RELEASE RING	1
10	497927-02	RETAINING CLIP	1
11	5100776-00	HUB CAP	1
12	000000-00	No Longer Available	1
13	5100199-00	TOP PLATE	1
14	5101899-01	PLATE	1
15	5100111-00	ACTUATOR FWR/REV	1
16	000000-00	No Longer Available	1
17	5100133-02	CLAMSHELL SET	1
19	498099-00	SCREW	2
21	5103070-05	NAMEPLATE	1
22	5100101-03	ACTUATOR	1
23	5100153-01	SHIFTER WIRE	1
24	5100035-01	SPRING	2
25	046376-00	PIN	1
28	607918-41	SCREWDRIVER BIT	1
30	5101893-06	IDENT. LABEL	1
861	5101955-02	KITBOX	1
866	HPB18	BATTERY	2
867	5102026-00	BATTERY CAP	1

Parts List for HPD1802 Type 3

Item Number	Part Number	Description	Qty Required
871	90504598	DUAL CHARGER	1