



Parts List for KG915K-B3 Type 2

Item Number	Part Number	Description	Qty Required
1	5140005-33	OUTER FLANGE	1
2	5140005-34	INNER FLANGE	1
3	569202-00	SCREW	3
4	569203-00	FLANGE	1
5	5140087-92	GUARD	1
6	5140040-53	SPINDLE	1
7	5140040-54	KEY	1
8	5140016-99	SPRING WASHER	1
9	569206-00	SCREW	4
10	5140087-93	GEAR BOX COVER	1
11	5140040-56	BEARING	1
12	5140040-57	SELF TAPPING SCREW	3
13	5140040-58	GEAR	1
14	5140040-59	CIRCLIP	1
15	5140040-60	BEARING	1
16	5140040-61	CIRCLIP	1
17	569176-00	SIDE HANDLE	1
18	5140040-62	GEAR BOX	1
19	569209-00	SCREW	4
20	5140040-63	BUTTON	1
21	5140040-64	SPRING	1
22	569175-00	NUT	1
23	5140040-65	PINION	1
24	569167-00	BEARING	1
25	569168-00	BRUSH HOLDER PLATE	1
26	569170-00	SCREW	2
27	5140040-66	ARMATURE	1

Parts List for KG915K-B3 Type 2

Item Number	Part Number	Description	Qty Required
28	5140040-68	BEARING	1
29	5140087-94	BEARING COVER	1
30	569172-00	BAFFLE	1
31	569173-00	SCREW	2
32	5140040-69	FIELD ASSY.	1
34	5140087-95	LEADWIRE	1
35	5140042-87	LEADWIRE	3
36	5140087-98	NAME PLATE	1
37	6010116-23	KNOB	1
38	5140088-01	ROD	1
39	5140088-02	SPRING	1
41	5140088-03	SWITCH ASSY.	1
42	5140088-04	FIELD CASE	1
43	5140088-05	BRAND LABEL	1
44	5140040-73	BRUSH BOX	2
45	596071-00	BRUSH	2
46	569189-00	WASHER	4
47	569188-00	SCREW	4
48	5140088-07	CORD CLAMP	1
49	569196-00	SCREW	2
50	569194-00	PROTECTOR	1
51	5140088-08	REAR COVER	1
52	569178-00	SCREW	1
53	5140088-09	CORD & PLUG	1
54	569197-00	SPANNER WRENCH	1
55	5140088-13	SPINDLE ASSY.	1
56	569164-00	GEARCASE	1

Parts List for KG915K-B3 Type 2

Item Number	Part Number	Description	Qty Required
57	5140070-72	ARMATURE ASSEMBLY	1
58	5140070-73	BRUSH BOX ASSY	1
59	5140088-14	FLANGE	1