



## Parts List for KS450-B3 Type 1

Item Number	Part Number	Description	Qty Required
1	5140041-54	HOUSING	1
2	5140041-55	HOUSING COVER	1
3	5140041-57	FIELD (120V)	1
4	5140041-59	ARMATURE (120V)	1
5	5140041-60	BLOCK	1
6	5140041-62	BRUSH CARBON	2
7	5140041-64	BRUSH HOLDER	2
8	5140041-65	MIDDLE HOLDER	1
9	5140041-66	SCREW	2
10	5140041-67	WASHER	1
11	5140041-68	WASHER	1
12	5140041-69	PLATE	2
13	5140041-70	WASHER	1
14	5140041-71	GEAR	1
15	5140041-72	WASHER	1
16	5140041-73	E-RING	1
17	5140041-74	ROLLER RING	1
18	5140041-75	SLIDE,BEARING	1
19	5140041-76	SHAFT ASSEMBLY	1
20	5140041-77	SCREW	1
21	5140041-78	ALLEN WRENCH	1
22	5140041-79	SPRING PLATE	2
23	5140041-80	PIN	2
24	5140041-81	LIMIT CHUTE	2
25	5140041-82	E-RING	2
26	5140041-83	GUIDE SHAFT	1
27	5140041-84	GUIDE WHEEL	1

## Parts List for KS450-B3 Type 1

Item Number	Part Number	Description	Qty Required
28	5140041-85	SWITCH	1
29	5140041-87	WIRE,SUPPORT	1
30	5140041-88	SPEED CONTROL	1
31	5140041-90	GUARD	1
32	5140041-91	LEAD WIRE	1
33	5140041-92	RETAINER	1
34	5140041-93	SPRING	1
35	5140041-94	LOCK	1
36	5140041-95	NUT	2
37	5140041-96	SHOE	1
38	5140041-97	PIN	1
39	5140041-98	PLATE	2
40	5140041-99	SCREW	2
41	5140042-00	GUIDE HOLDER	1
42	5140042-01	SCREW	8
43	5140042-04	NAME PLATE	1
44	5140042-06	CORD CLAMP	1
45	5140042-07	SCREW	2
46	5140042-10	CORD SET	1
47	5140042-12	CORD PROTECTOR	1