







Parts Breakdown

LS1040F

Products with multiple versions are listed in subsiding order with the newest version on top not indented

<u>Fig #</u>	<u>Part ID</u>	<u>Part Name</u>	<u>Quantity</u>
1	416004-6	HANDLE COVER, LS1040	1
2	211206-7	B. BEARING 6202LLB, NHP1310	1
3	267280-3	FLAT WASHER 15, LS1011N	1
4	343641-2	SHAFT LOCK, LS1030	1
5	241909-9	FAN 80, LS1030N	1
6	516716-2	ARMATURE 115V, LS1040	1
7	681640-9	INSULATION WASHER, LS1040	1
8	211061-7	B. BEARING 6000LLB, 6222DWE	1
9	416442-2	BAFFLE PLATE, LS1045	1
10	526066-7	FIELD ASS'Y 115V, LS1045	1
11	265995-6	TAPPING SCREW 4X18, 4323K	2
12	687052-4	STRAIN RELIEF, HM1500B	1
13	664463-0	CORD (2X14X8 SJ), 2414B	1
14	682505-8	CORD GUARD, 2711	1
15	850407-8	NAME PLATE, LS1040F	1
16	265995-6	TAPPING SCREW 4X18, 4323K	3
17	911383-2	P.H. SCREW M6X60, LS1030	4
18	411478-6	SWITCH BUTTON, LS1011	1
19	643650-4	BRUSH HOLDER CAP, 5007MG	2
20	181047-4	CARBON BRUSH SET 154,5402A	1
20	194986-9	CARBON BRUSH SET CB-154, UC3530A	1
21	153799-7	MOTOR HOUSING CPL., LS1040F	1
22	651923-1	SWITCH, LS1040	1
23	231457-6	COMP. SPRING 3, HR2400	1
24	416000-4	LOCK OFF LEVER, LS1040	1
25	415999-0	SWITCH LEVER, LS1040	1
26	414546-4	CAM, LS1011	1
27	266029-8	T. SCREW FLANGE PT 5X65, JR3020	2
28	231297-2	COMP. SPRING 9, LS1011	1
29	251667-9	H. BOLT M8X75, LS1030	1
30	262511-5	RUBBER SLEEVE 6, LS1030	1
31	265995-6	TAPPING SCREW 4X18, 4323K	1
32	416007-0	GUIDE COVER, LS1040	1
33	226465-0	HELICAL GEAR 42, LS1040	1
34	316821-3	HOUSING W/O BEARING, LS1040	1
35	211256-2	B. BEARING 6203LLB, GA7001L	1
36	285685-5	BEARING RETAINER 64, LS1040	1
37	322865-3	SPINDLE, LS1040	1
38	224333-1	FLANGE 53, LS1040	1
39	224333-1	FLANGE 53, LS1040	1
40	265355-2	H. F. H. BOLT, LS1030	1
41	343639-9	CENTER PLATE, LS1030	1
42	344380-7	CENTER COVER, LS1040	1
43	265324-3	H.F.H. BOLT M8X12, LS1030	1
44	231593-8	TORSION SPRING 36, LS1030	1
45	416003-8	SAFETY COVER, LS1040	1
46	267136-0	FLAT WASHER 5, 9046	1
47	911213-7	P.H. SCREW M5X12, LS1040	1
48	265985-9	HEX.SOCKET HEAD BOLT M6, LS1211	1
49	911223-4	P.H. SCREW M5X16, 4301BV	2
50	819064-1	MAKITA MARK, 5402NA	1
50	819214-8	MAKITA LOGO LABEL, LS1013L	1
51	151451-1	BLADE CASE CP., LS1040	1
51	151451-1	BLADE CASE CP., LS1040	1
51	188324-5	BLADE CASE SET, LS1040F	1
51	188324-5	BLADE CASE SET, LS1040F	1
52	265488-3	HEX. BOLT M8 X30, LS1040	4
53	316826-3	GUIDE RULE, LS1040	1
53	316826-3	GUIDE RULE, LS1040	1
54	912342-9	C.S.H. SCREW M6X25, LS1040	1
55	253715-0	F. WASHER 6, NHP1310	1
56	150662-5	SUB FENCE CP., LS1040	1
56	150662-5	SUB FENCE CP., LS1040	1
57	344476-4	SUB FENCE PLATE, LS1040	1



Parts Breakdown

LS1040F

58	252014-7	HEX LOCK NUT M6-10, LS1040	1
59	251961-9	H.S.H. SCREW M6X10, LS1040	1
60	257162-7	RING 7, LS1030	1
61	253823-7	F. WASHER 7, LS1011	1
62	265984-1	H.S.B. HEAD BOLT M6, LS1040	1
63	344377-6	LINK PLATE, LS1040	1
64	265984-1	H.S.B. HEAD BOLT M6, LS1040	1
65	253823-7	F. WASHER 7, LS1011	1
66	257162-7	RING 7, LS1030	1
67	416006-2	LEVER 100, LS1040	1
68	911113-1	P.H. SCREW M4X10, 4301BV	1
69	265437-0	HEX BOLT M10, LS1040	1
70	253024-7	F. WASHER 10, LS0714	1
71	256836-7	ROD 16, LS1040	1
72	150664-1	ARM CP., LS1040-T1	1
72	150664-1	ARM CP., LS1040-T1	1
72	154463-3	ARM COMPLETE, LS1040F-T2	1
73	322317-4	STOPPER PIN, LS1040	1
74	213021-5	O RING 5, JR3070CT	1
75	233152-4	COMP. SPRING 28, LS1040	1
76	344464-1	SPRING HOLDER, LS1013	1
77	256280-8	PIN 8, LS1030N	1
79	911113-1	P.H. SCREW M4X10, 4301BV	1
80	344385-7	POINTER, LS1040	1
81	343799-7	SLIDE PLATE, LS1040	3
82	921452-1	HEX BOLT M8X30,LS1040	1
83	911213-7	P.H. SCREW M5X12, LS1040	2
84	273495-2	GRIP 32, LS1030	1
85	344381-5	KNOCK SPRING, LS1040	1
86	150585-7	BASE CP., LS1040	1
86	150585-7	BASE CP., LS1040	1
87	316824-7	TURN BASE, LS1040	1
87	316824-7	TURN BASE, LS1040	1
88	416001-2	KERF BOARD, LS1040	1
89	416001-2	KERF BOARD, LS1040	1
90	921452-1	HEX BOLT M8X30,LS1040	1
91	931402-8	HEX NUT M8, 5037NB	1
92	252105-4	HEX LOCK NUT M8-13, HM1800	1
93	253762-1	F. WASHER 8, LS1040	1
94	931402-8	HEX NUT M8, 5037NB	1
95	921452-1	HEX BOLT M8X30,LS1040	1
97	251887-5	SCREW M6X10, LS1030	1
110	266091-3	TAPPING SCREW 4X50, 6812	2
111	125178-9	LIGHT ASS'Y, LS104F	1
112	418072-5	SUPPORTER, LS1040F	1
1,001	411478-6	SWITCH BUTTON, LS1011	2
1,002	762001-3	TRIANGLE RULE, LS1011	1
1,003	782212-4	SOCKET WRENCH 13, LS1011	1
1,004	122523-9	DUST BAG, LS1040	1
1,005	193471-9	SUB PLATE ASS'Y, LS1040F	1
1,006	122536-0	VICE ASS'Y, LS1040F	1
5,001	810251-5	N/A	1