



Parts List for M700 Type 1

Item Number	Part Number	Description	Qty Required
1	000000-00	No Longer Available	1
2	000000-00	No Longer Available	1
3	90508746	SWITCH LEVER	1
4	000000-00	No Longer Available	1
5	330019-13	SCREW,M4X19	7
6	681269-00	SPRING	1
7	99292-16	SCREW	1
8	038738-00	NUT	1
9	000000-00	No Longer Available	1
10	000000-00	No Longer Available	1
11	000000-00	No Longer Available	4
12	5130830-00	FLAT WASHER	8
13	239540-05	HUB CAP	4
15	73093-00	BEARING,SLEEVE	1
17	000000-00	No Longer Available	1
18	000000-00	No Longer Available	1
19	239478-05	BOLT, AXLE	4
20	000000-00	No Longer Available	2
21	90566348	HANDLE GRIP	1
22	000000-00	No Longer Available	4
23	000000-00	No Longer Available	1
24	90542737	KNOB ASSEMBLY	4
26	242238-01	MOTOR ASSY.	1
27	681086-02	MAGNET RING	1
28	000000-00	No Longer Available	1
29	241201-00	LEVER	4
30	241205-02	SUPPORT ARM	4

Parts List for M700 Type 1

Item Number	Part Number	Description	Qty Required
31	239539-02	TIP, LEVER	4
32	239477-01	NUT,HEX	4
33	000000-00	No Longer Available	1
34	000000-00	No Longer Available	1
35	241054-00	BLADE	1
36	000000-00	No Longer Available	1
37	680812-00	SPACER,BLADE	1
38	241381-01	INSULATOR,BLADE	1
39	241125-00	FAN	1
40	90561895	HEX NUT	1
41	092715-00	SPACER	1
42	000000-00	No Longer Available	1
43	070055-00	BALL BEARING	1
44	680476-07	CAP,END	1
45	243679-00	SCREW	4
46	000000-00	No Longer Available	1
47	000000-00	No Longer Available	1
48	000000-00	No Longer Available	1
49	000000-00	No Longer Available	1
50	000000-00	No Longer Available	1
51	000000-00	No Longer Available	1
52	000000-00	No Longer Available	2
53	681298-00	SCREW	2
54	099361-10	WASHER	2
55	32699-00	NUT	2
56	240808-01	CAP,BRUSH	2
57	242207-00	SPRING,BRUSH	2

Parts List for M700 Type 1

Item Number	Part Number	Description	Qty Required
58	070162-00	TERMINAL	2
60	137203-00	RING, RETAINING	1
61	000000-00	No Longer Available	1
62	000000-00	No Longer Available	1
63	239715-06	WRAP,TIE	3
64	062443-02	CLAMP	1
65	72954-00	SCREW	1
66	000000-00	No Longer Available	1
67	242274-00	INSERT,BRUSH	2
68	000000-00	No Longer Available	1
69	000000-00	No Longer Available	1
71	000000-00	No Longer Available	1
72	242273-00	BRUSH,SHUNTED	2
73	33314-00	CONNECTOR	2
74	000000-00	No Longer Available	1
75	000000-00	No Longer Available	1
76	000000-00	No Longer Available	1
77	000000-00	No Longer Available	1
78	000000-00	No Longer Available	1
79	000000-00	No Longer Available	1
80	000000-00	No Longer Available	1
81	66515-00	WASHER	4
82	000000-00	No Longer Available	1
83	000000-00	No Longer Available	1
84	000000-00	No Longer Available	1
85	000000-00	No Longer Available	1
86	681064-01	SWITCH,P.BUTTON	1

Parts List for M700 Type 1

Item Number	Part Number	Description	Qty Required
87	86492-00	NUT	4
88	000000-00	No Longer Available	1