


846



## Parts List for PC136MS Type 1

Item Number	Part Number	Description	Qty Required
1	5140092-64	LEG EXT.	1
4	5140092-65	RT WHEEL CONNECTOR	1
5	5140092-66	LT WHEEL CONNECTOR	1
8	5140092-67	FRONT FOOT TUBE	1
10	5140092-68	EXTENSION	1
13	5140092-69	EXT. WORK SUPPORT	2
14	5140092-70	EXT. WORK SUPPORT	2
15	5140092-71	BUSHING	2
18	5140092-85	EXTENSION STOP	2
20	5140092-72	EXTENSION	1
21	5140092-73	HANDLE BAR	1
22	5140092-74	WHEEL	2
23	5140092-75	END CAP	2
24	5140092-76	PLASTIC INSERT	8
25	5140092-77	PISTON	1
27	5140092-78	HEX WRENCH	1
39	5140092-79	LOCK KNOB	2
40	5140092-80	SET SCREW	2
65	5140092-81	CABLE	1
66	5140092-82	CABLE	1
70	5140092-83	LOCK KNOB	2
73	A11965	COVER	1
846	5140092-84	HARDWARE PACK	1