



871

866



Parts List for PC1800AG Type 1

Item Number	Part Number	Description	Qty Required
1	5140014-92	OUTER FLANGE	1
2	5140070-37	INNER FLANGE	1
3	5140070-38	GUARD ASSY	1
4	596437-00	SIDE HANDLE	1
5	5140070-39	GUARD ASSY	1
6	596440-00	WRENCH	1
866	90543485	18V BATTERY	1
866	PC18B	BATTERY PACK	1
871	90550550-02	CHARGER	1
871	90545445	CHARGER	1