



Parts List for PC1800JS Type 1

Item Number	Part Number	Description	Qty Required
3	582593-00	BLADE CLAMP	1
8	90543284	SHOE	1
21	582600-00	LOCKING SCREW	1
22	582730-00	BRACKET	1
100	858274-00	RIP FENCE	1
101	859597-00	CLAMP	1
102	587210-00	SCREW	1
856	90550875	VACUUM ADAPTER	1
866	PC18B	BATTERY PACK	1
866	90543485	18V BATTERY	1
867	90535852	CAP,BATTERY	1
871	90550550-02	CHARGER	1
871	90545445	CHARGER	1