



Parts List for PC1800L Type 1

Item Number	Part Number	Description	Qty Required
1	90534275	KRYPTON BULB	1
2	90534780	FLASHLIGHT	1
866	90543485	18V BATTERY	1
871	90545445	CHARGER	1