



Parts List for PC1800SS Type 1

Item Number	Part Number	Description	Qty Required
1	90527000	WRENCH	1
2	90527040	DUST CHUTE	1
3	90526993	CIRCLE CUTTER	1
4	90526994	DEPTH ADJ ASSY	1
5	90526996	COLLET,1/4	1
5	90526995	COLLET,1/8	1
7	90526997	COLLET NUT	1
856	DW6603	DRYWALL/OUTLET BIT-3 FLUT	1
856	DW6601	GENERAL PURPOSE BIT	1
866	PC18B	BATTERY PACK	1
866	90543485	18V BATTERY	1
871	90550550-02	CHARGER	1
871	90545445	CHARGER	1