



Parts List for PCB370SS Type 1

Item Number	Part Number	Description	Qty Required
1	5140077-37	STICKER	1
2	5140078-36	SPRING	1
3	5140078-37	COMPRESSION SPRING	1
4	5140078-38	WASHER	1
5	5140078-39	PLATE	2
8	5140078-40	BEARING SEAT	1
9	5140078-41	UPPER ARM ASSY	1
10	5140078-42	BELLOWS	1
11	5140078-43	PLUG,HOUSING	1
12	5140078-44	PVC HOSE	1
13	5140078-45	EXTENSION SPRING	1
14	5140078-46	DUST SHIELD	4
15	5140078-47	CORD CLAMP	4
16	5140078-48	PLUNGER HOUSING	1
17	5140078-49	PIVOT SHAFT	1
18	5140078-50	HEX WRENCH	1
19	5140078-51	FLAT WASHER	1
20	5140078-52	FLAT WASHER	7
21	5140078-53	SPRING WASHER	2
22	5140078-54	LOCK WASHER	1
23	5140078-55	WAVY WASHER	1
24	5140078-56	WAVY WASHER	2
25	5140078-57	SPRING PIN	1
26	5140078-58	HEX HEAD BOLT	5
27	5140078-59	HEX HD BOLT	2
28	5140078-60	HEX HEAD BOLT	1
29	5140078-61	HEX. SOC. HD. BOLT	1

Parts List for PCB370SS Type 1

Item Number	Part Number	Description	Qty Required
30	5140078-62	HEX. SOC. HD. BOLT	1
31	5140078-63	HEX SOC HD SCR	1
32	5140078-64	HEX SOC HD SCR	2
33	5140078-65	HEX SOC HD SCR	3
34	5140078-66	SCREW	2
35	5140078-67	SCREW	1
36	5140078-68	SCREW	1
37	5140078-69	SCREW	1
38	5140078-70	SCREW	2
39	5140078-71	SCREW	2
40	5140077-71	SCREW	2
41	5140078-72	SCREW	2
42	5140078-73	SCREW	4
43	5140078-74	SCREW	1
44	5140078-75	SCREW	4
45	285304-00	SCREW	9
46	5140078-76	SCREW	4
47	5140078-77	SCREW	2
48	5140078-78	LOCK NUT	1
49	284867-00	CHUCK,NUT	1
50	5140078-79	LOCK NUT	1
51	5140078-80	STRAIN RELIEF	1
52	5140078-81	CORD SET	1
53	5140078-82	CIRCUIT BRKR/SWITCH	1
54	5140078-83	STEEL BALL	1
55	5140078-84	SCREW	1
56	5140078-85	BEARING SEAT	1

Parts List for PCB370SS Type 1

Item Number	Part Number	Description	Qty Required
57	5140078-86	BUSH	1
58	5140078-87	HOUSING	1
59	5140078-88	BLADE BOX	1
60	5140078-89	PLATE,COVER	1
61	5140078-90	BOTTOM ARM ROCKER	1
62	5140078-91	CONNECTOR BOX	1
63	5140078-92	CONNECTOR BOX COVER	1
64	5140078-93	HEX SOC HD SCR	2
65	5140078-94	TURNTABLE	1
66	5140078-95	SPRING GUARD	1
67	5140078-96	SWITCH BOX	1
68	5140078-97	BASE	1
69	5140078-98	TABLE	1
70	5140078-99	TILT BRACKET	1
71	5140079-00	TRUNNION BRACKET	1
72	5140079-01	SCREW	2
73	5140079-02	TURN TABLE COVER	1
74	5140079-03	PLATE, COVER	1
75	5140079-04	GUIDE HOLDER	1
76	5140079-05	COVER	1
77	5140079-06	GUIDE BLOCK	1
78	5140079-07	WIRE ROPE ASSY.	1
79	5140079-08	HOUSING,RIGHT	1
80	5140079-09	RETAINING CLIP	1
81	5140079-10	FOOT	4
82	5140079-11	HEX SOC HD SCR	1
83	5140079-12	INSERT	1

Parts List for PCB370SS Type 1

Item Number	Part Number	Description	Qty Required
84	5140079-13	HOLD DOWN ROD	1
85	5140079-14	MOTOR ASSY.	1
86	5140079-15	CONTROLLER ASSY	1
87	5140079-16	ROCKER SWITCH	2
88	5140079-17	LEAD WIRE ASSY	1
89	5140079-18	LAMP ASSY.	1
90	5140079-19	PUSH BUTTON	1
91	5140079-20	AIR DUCT	1
92	5140079-21	CLAMP, GUIDE	1
93	5140079-22	INDICATED BUTTON	1
94	5140079-23	TENSION HANDLE	1
95	5140079-24	PLUNGER HANDLE	1
96	5140079-25	HANDLE	1
97	5140079-26	BLADE HOLDER ASSY.	1
98	5140079-27	BLADE HOLDER ASSY.	1
99	5140079-28	FOLLOWER PLATE	1
101	5140079-29	LABEL	1
102	5140079-30	CAUTION LABEL	1
103	5140079-31	LABEL	1
104	5140079-32	LABEL	1
105	5140079-33	WARNING LABEL	1
106	5140079-34	LABEL	1
107	5140079-35	LABEL	1
108	5140079-36	WARNING LABEL	1
109	5140079-37	LABEL	1
110	5140079-38	TILTING SCALE	1
111	5140079-39	SWITCH BOX COVER	1

Parts List for PCB370SS Type 1

Item Number	Part Number	Description	Qty Required
112	5140079-40	LINKAGE BAR ASSY.	1
113	5140079-41	ECCENTRIC ASSY.	1
215	5140079-43	FLAT WASHER	4
216	5140079-44	HEX HEAD BOLT	4
217	5140079-45	CARRIAGE BOLT	16
218	5140079-46	FLANGED HEX NUT	20
219	5140079-47	SLEEVE	4
220	5140079-48	LONG UPPER SUPPORT	2
221	5140079-49	SHORT UPPER SUPPORT	2
222	5140079-50	LEG	4
223	5140079-51	LONG SUPPORT BRKT	2
224	5140079-52	SHORT SUPPORT BRKT	2
226	5140079-54	CUSHION	4
227	5140079-55	WARNING LABEL	1
846	5140079-56	HARDWARE BAG	1
856	5140079-53	STAND ASSY	1