



## Parts List for PCB660DP Type 1

Item Number	Part Number	Description	Qty Required
1	5140077-35	SWITCH BOX	1
2	5140077-36	FLAT WASHER	1
3	5140077-37	STICKER	1
4	5140077-38	COLUMN ASSY.	1
5	5140077-39	MOTOR PULLEY	1
6	5140077-40	BASE	1
7	5140077-41	WORM	1
8	5140077-42	CRANK HANDLE	1
9	5140077-43	TABLE	1
10	760084-00	RACK	1
11	5140077-44	RING ASSEMBLY	1
12	5140077-45	HANDLE	1
13	5140077-46	SHIFTER ASSY.	1
14	5140077-47	ROD	1
15	761410-00	BOLT, BAR SLIDE	1
16	760095-00	BASE,MOTOR	1
17	5140077-48	SCALE RING	1
18	5140077-49	SET SCREW	1
19	761419-00	NUT,PULLEY LOCK	1
20	5140077-50	SPINDLE PULLEY	1
21	5140077-51	WEDGE	1
22	5140077-52	CHUCK KEY HOLDER	1
23	5140077-53	ROD	1
24	5140077-54	CORD CLAMP	1
25	5140077-55	ARBOR	1
26	5140077-56	HEX WRENCH	1
27	5140077-57	HEX WRENCH	1

## Parts List for PCB660DP Type 1

Item Number	Part Number	Description	Qty Required
28	5140077-58	HEX WRENCH	1
29	5140077-59	FLAT WASHER	1
30	5140077-60	FLAT WASHER	1
31	5140077-61	FLAT WASHER	4
32	285314-00	WASHER,FLAT	1
33	5140077-62	SPRING WASHER	3
34	283716-00	WASHER,LOCK	2
35	5140077-63	SPRING PIN	2
36	5140077-64	V-BELT	1
37	5140077-65	V-BELT	1
38	5140077-66	BOLT	4
39	5140077-67	BOLT	1
40	283700-00	SCREW	2
41	285403-00	SCREW & WASHER	4
42	5140077-68	SCREW	2
43	5140077-69	SCREW	5
44	5140077-70	SCREW	2
45	284925-00	SCREW	4
46	5140077-71	SCREW	1
47	5140077-72	SCREW	5
48	285304-00	SCREW	3
49	5140077-73	SCREW	5
50	5140077-74	SCREW	2
51	5140077-75	HEX NUT	1
52	5140077-76	HEX NUT	1
53	5140077-77	HEX NUT	2
54	5140077-78	HEX NUT	4

## Parts List for PCB660DP Type 1

Item Number	Part Number	Description	Qty Required
55	5140077-79	HEX NUT	2
56	5140077-80	HEX NUT	1
57	5140077-81	STRAIN RELIEF	1
58	5140077-82	STRAIN RELIEF	2
59	284867-00	CHUCK,NUT	2
60	5140077-83	LEAD ASSY.	1
61	5140077-84	ROCKER SWITCH	1
62	5140077-85	CHUCK KEY	1
63	5140077-86	SPRING PLATE	1
64	5140077-87	PULLEY	1
65	5140077-88	HUB	1
66	5140077-89	CABLE TIE	1
67	5140077-90	COVER	1
68	5140077-91	CUSHION	1
69	5140077-92	SHAFT ASSEMBLY	1
70	5140077-93	LOCK HANDLE	1
71	5140077-94	LOCK HANDLE	1
72	5140077-95	TABLE BRACKET ASSY	1
73	5140077-96	SET BOLT	2
74	5140077-97	LASER ASSEMBLY	2
75	5140078-28	SPEED CHART	1
76	5140078-33	ID LABEL	1
77	5140077-99	WARNING LABEL	2
78	5140078-00	WARNING LABEL	2
79	5140078-26	WARNING LABEL	1
80	5140078-01	CORD CLAMP	3
81	5140078-02	COVER PLATE	1

## Parts List for PCB660DP Type 1

Item Number	Part Number	Description	Qty Required
82	5140078-03	COVER	2
83	5140078-04	SWITCH COVER	1
84	5140078-05	LEAD ASSY.	1
85	5140078-27	WARNING LABEL	1
86	5140078-06	PLUNGER HOUSING	1
87	5140078-07	LOCKING RING	1
88	5140078-08	ADJUSTING NUT	1
89	5140078-09	COMPRESSION SPRING	1
90	5140078-10	POWER CABLE	1
91	5140078-11	LAMP	1
92	5140078-12	CONTROLLER ASSY	1
93	5140078-13	MOTOR ASSEMBLY	1
94	5140078-14	ROCKER SWITCH	1
95	5140078-15	HEAD	1
97	5140078-17	NUT	1
98	5140078-18	PULLEY COVER	1
99	5140078-19	POWER CABLE	1
100	5140078-20	BRACKET	1
101	5140078-21	SLEEVE ASSY	1
102	5140078-22	SPINDLE ASSEMBLY	1
103	5140078-23	SET COLLAR ASSY	1
104	5140078-24	RING ASSEMBLY	1
105	5140078-25	LABEL	1
106	5140078-29	SCALE	1
107	5140078-30	CHUCK & KEY	1
108	5140078-31	HANDLE SET	1
110	5140077-98	KEY	1

## Parts List for PCB660DP Type 1

Item Number	Part Number	Description	Qty Required
846	5140078-16	HARDWARE BAG	1