



Parts List for PI50-B3 Type 1

Item Number	Part Number	Description	Qty Required
1	187960-00	ARMATURE	1
2	187997-00	FIELD (120V)	1
3	185557-02	SWITCH,SIN.SPD.	1
4	187499-00	BRUSH & HOLDER ASSY	2
5	875735	BRUSH HOLDER	2
6	184545-28	CORD & PLUG	1
7	188188-00	NAME PLATE	1
8	187926-01	CLAMSHELL SET	1
9	187967-02	ACTUATOR	1
10	186452-00	THRUST PLATE	1
11	187965-00	BEARING BLOCK ASSY.	1
12	574297-00	BEARING,SINTER	1
13	821986	SPRING	1
14	748180-02	GEAR	1
15	187962-00	SPINDLE	1
16	330033-15	CHUCK,10MM	1
17	330034-07	CHUCK KEY	1
18	187998-03	LEADWIRE	1
19	187998-02	LEAD WIRE	1
20	635176-00	BEARING SLEEVE	1
21	606290-01	BEARING	2
23	330019-04	SCREW,PLASTITE	8
24	188189-00	ID LABEL	1