



Parts List for PS1200K Type 3

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|-----------------|--------------|
| 1 | 149518-01 | SCREW | 1 |
| 2 | 5147554-00 | KEYLESS CHUCK | 1 |
| 3 | 5102766-19 | VSR SWITCH | 1 |
| 4 | 607918-41 | SCREWDRIVER BIT | 1 |
| 5 | 5148202-00 | MOTOR & GEARBOX | 1 |
| 6 | 311978-01 | F/R ACTUATOR | 1 |
| 7 | 148354-03 | BIT CLIP | 1 |
| 861 | 499124-13 | KIT BOX | 1 |
| 866 | HPB12 | BATTERY PACK | 1 |
| 867 | 5102026-00 | BATTERY CAP | 1 |
| 871 | 90500926 | CHARGER | 1 |