



Parts List for PS7240K Type 1

Item Number	Part Number	Description	Qty Required
1	149518-01	SCREW	1
2	419233-07	CHUCK,KEYLESS	1
3	5101240-00	SPRING PIN	1
4	148354-03	BIT CLIP	1
5	311978-01	F/R ACTUATOR	1
6	311993-00	SCREW	6
7	498511-00	SCREW	1
8	5100850-11	TRANSMISSION	1
9	5102550-07	SWITCH,2 SPEED	1
14	5102758-04	CLAMSHELL	1
15	497785-00	MOTOR & PINION	1
16	5102759-03	NAMEPLATE	1
17	5102537-01	ID LABEL	1
856	607918-41	SCREWDRIVER BIT	1
856	498797-05	BULB	1
861	497641-05	LATCH	2
861	499124-13	KIT BOX	1
866	419574-03	BATTERY	1
867	645221-00	BATTERY CAP	1
871	90500925-01	CHARGER	1
871	418352-05	CHARGER	1