





## Parts List for PW1600-B3 Type 1

| Item Number | Part Number | Description    | Qty Required |
|-------------|-------------|----------------|--------------|
| 1           | JH120001    | UPPER HANDLE   | 1            |
| 2           | JH120002    | HANDLE COVER   | 1            |
| 3           | JH120003    | HANDLE COVER   | 1            |
| 4           | JH120004    | HANDLE COVER   | 1            |
| 5           | JH120005    | CORD WRAP      | 1            |
| 6           | JH120006    | CONNECTOR TUBE | 2            |
| 7           | JH120007    | HOUSING,MAIN   | 1            |
| 8           | JH120008    | WHEEL COVER    | 2            |
| 9           | JH110009    | LOCKING NUT    | 2            |
| 10          | JH120011    | SCREW          | 6            |
| 11          | JH110010    | WASHER         | 2            |
| 12          | JH120012    | SCREW          | 1            |
| 13          | JH120013    | SCREW          | 33           |
| 14          | JH120014    | WHEEL HUB      | 2            |
| 16          | JH110017    | RUBBER WASHER  | 2            |
| 17          | JH120016    | WHEEL SHAFT    | 1            |
| 18          | JH120015    | TOP COVER      | 1            |
| 19          | JH0103      | SWITCH         | 1            |
| 20          | JH110020    | LOCK KNOB      | 1            |
| 21          | JH110021    | SPRING         | 1            |
| 22          | JH110022    | WASHER         | 2            |
| 23          | JH110023    | LOCK WASHER    | 1            |
| 24          | JH110024    | SWITCH BOX     | 1            |
| 25          | JH110025    | HOUSING,LEFT   | 1            |
| 26          | JH110027    | SLEEVE         | 1            |
| 28          | JH110029B3  | PLUG           | 1            |
| 29          | JH0120BR    | CORD & PLUG    | 1            |

## Parts List for PW1600-B3 Type 1

| Item Number | Part Number | Description        | Qty Required |
|-------------|-------------|--------------------|--------------|
| 30          | JH110031BR  | MOTOR              | 1            |
| 31          | JH110028    | CORD CLIP          | 1            |
| 32          | JH110032    | TERMINAL           | 4            |
| 33          | JH110034    | O-RING             | 1            |
| 34          | JH110035    | CAP                | 1            |
| 35          | JH110033    | TANK CONNECTION    | 1            |
| 36          | JH110037    | PVC WASHER         | 1            |
| 38          | JH110036    | TANK CONNECTION    | 1            |
| 39          | JH110039    | FILTER ASSY.       | 1            |
| 40          | JH110040    | CAP                | 1            |
| 41          | JH110041    | SPRING             | 1            |
| 42          | JH110042    | DETERGENT BOTTLE   | 1            |
| 45          | JH110045    | SUPPORT,MOTOR      | 2            |
| 46          | JH0058      | PLASTIC NUT        | 1            |
| 47          | JH0059      | FILTER             | 1            |
| 48          | JH110048    | WATER CONNECTOR    | 1            |
| 49          | JH110049    | QUICK CONNECT      | 1            |
| 50          | JH120050    | WARNING LABEL      | 1            |
| 51          | JH120051    | LABEL              | 1            |
| 52          | JH120052    | LABEL              | 1            |
| 53          | JH120053    | NAME PLATE         | 1            |
| 54          | JH120054    | SELF TAPPING SCREW | 6            |
| 56          | JH120056    | SELF TAPPING SCREW | 2            |
| 57          | JH110038    | TUBE               | 1            |
| 58          | JH120058    | TOOL HOLDER        | 1            |
| 59          | JH120059    | TOOL HOLDER        | 1            |
| 60          | JH0121      | HOSE GUN ASSY.     | 1            |

## Parts List for PW1600-B3 Type 1

| Item Number | Part Number | Description        | Qty Required |
|-------------|-------------|--------------------|--------------|
| 61          | JH110061    | CONNECTOR TUBE     | 1            |
| 63          | JH110063    | WATER OUTLET COVER | 1            |
| 65          | JH110065    | WAND / LANCE       | 1            |
| 66          | JH0123      | TURBO WAND         | 1            |
| 67          | JH110067    | PRESSURE HOSE      | 1            |
| 68          | JH0132      | O-RING             | 2            |
| 69          | JH120069    | HARDWARE BAG       | 1            |
| 70          | JH0125      | CLEAN OUT PIN      | 1            |
| 73          | JH120073    | PUMP ASSEMBLY      | 1            |
| 75          | JH110018    | O-RING             | 1            |
| 76          | JH110026    | ACCESSORY HOLDER   | 1            |
| 101         | JHMP0001    | MOTOR SHROUD       | 1            |
| 102         | JHMP0002    | FAN HOOP           | 1            |
| 103         | JHMP0003    | FAN                | 1            |
| 104         | JHMP0004    | LOCK WASHER        | 1            |
| 105         | JHMP0005    | SCREW              | 4            |
| 106         | JHMP0006    | MOTOR CAP          | 1            |
| 107         | JHMP0007B3  | STATOR             | 1            |
| 108         | JHMP0008    | TUBING             | 3            |
| 109         | JHMP0009    | NYLON LOCKER       | 1            |
| 110         | JHMP0010    | TERMINAL           | 4            |
| 111         | JHMP0011    | CAP                | 4            |
| 112         | JHMP0012    | BEARING            | 1            |
| 113         | JHMP0013B3  | ROTOR              | 1            |
| 114         | JHMP0014    | OIL SEAL           | 2            |
| 115         | JHMP0015    | SCREW              | 1            |
| 116         | JHMP0016    | SCREW              | 1            |

## Parts List for PW1600-B3 Type 1

| Item Number | Part Number | Description      | Qty Required |
|-------------|-------------|------------------|--------------|
| 117         | JHMP0017    | FRONT CAP        | 1            |
| 118         | JHMP0018    | BEARING          | 1            |
| 119         | JHMP0019    | HEX BOLT         | 3            |
| 120         | JHMP0020    | O-RING           | 1            |
| 121         | JHMP0021    | WOBBLE PLATE     | 1            |
| 122         | JHMP0022    | THRUST BEARING   | 1            |
| 123         | JHMP0023    | SCREW            | 1            |
| 124         | JHMP0024    | PISTON ASSY      | 3            |
| 125         | JHMP0025    | SPRING PISTON    | 3            |
| 126         | JHMP0026    | PUMP BODY        | 1            |
| 127         | JHMP0027    | OIL SEAL         | 3            |
| 128         | JHMP0028    | RETAINER,SEAL    | 3            |
| 129         | JHMP0029    | RETAINER RING    | 3            |
| 130         | JHMP0030    | SEAL             | 3            |
| 131         | JHMP0031    | LOCK WASHER      | 3            |
| 132         | JHMP0032    | CHECK VALVE ASSY | 3            |
| 133         | JHMP0033    | VALVE ASSEMBLY   | 1            |
| 134         | JHMP0034    | SEAL             | 1            |
| 135         | JHMP0035    | GROMMET          | 1            |
| 136         | JHMP0036    | SWITCH BOX       | 1            |
| 137         | JHMP0037AR  | SWITCH           | 1            |
| 138         | JHMP0038AR  | CAPACITOR        | 1            |
| 139         | JHMP0039    | SEAL             | 1            |
| 140         | JHMP0040    | SWITCH COVER     | 1            |
| 141         | JHMP0041    | COVER            | 1            |
| 142         | JHMP0042    | VALVE ASSY       | 1            |
| 143         | JHMP0043    | WATER OUTLET     | 1            |

## Parts List for PW1600-B3 Type 1

| Item Number | Part Number | Description      | Qty Required |
|-------------|-------------|------------------|--------------|
| 144         | JHMP0044    | O-RING           | 1            |
| 145         | JHMP0045    | NOZZLE           | 1            |
| 146         | JHMP0046    | CHECK VALVE ASSY | 1            |
| 147         | JHMP0047    | HEX SCREW        | 4            |
| 148         | JHMP0048    | COVER            | 1            |
| 149         | JHMP0049    | PIN              | 1            |
| 150         | JHMP0050    | O-RING           | 3            |
| 151         | JHMP0051    | SCREW            | 1            |
| 152         | JHMP0052    | O-RING           | 1            |
| 153         | JHMP0053    | PUMP BODY        | 1            |
| 154         | JHMP0054    | RING             | 1            |
| 155         | JHMP0055    | WATER INLET      | 1            |
| 156         | JHMP0056    | HEX HEAD SCREW   | 4            |
| 157         | JHMP0057    | HEX HEAD SCREW   | 4            |
| 158         | JHMP0058    | LEAD             | 1            |
| 159         | JHMP0059AR  | CORD             | 1            |
| 160         | JHMP0060AR  | TERMINAL         | 2            |
| 161         | JHMP0061AR  | COVER            | 2            |
| 162         | JHMP0062    | WASHER           | 3            |
| 163         | JHMP0063    | SPRING           | 1            |
| 164         | JHMP0064    | STEEL BALL       | 1            |
| 165         | JHMP0065    | O-RING           | 1            |