



## Parts List for SC7 Type 0

Item Number	Part Number	Description	Qty Required
1	TL770216	SCREW- BHCS #10-24x1	4
2	B04582	CAP- END SC7	1
3	000000-00	No Longer Available	1
4	SC10	O RING	1
5	B04580	PISTON- (STD)	1
6	SC102	BUSHING- PISTON ROD	1
7	SC08	O RING	5
8	SC23	SCREW- SET	2
9	1753	PLUG- MANIFOLD 1/8-2	1
10	SC05	PIN- ROLL	3
11	B04581	ROD- PISTON (STD)	1
12	B01440	ROLLER	1
13	SC01	ROLLER PIN	2
14	B01503F	FEEDER BLADE	1
15	B04584F	SIDE PLATE- SC7	2
16	SC77	NYLOCK NUT THIN 10-2	2
17	B01438F	SPRING- LATCH	1
18	B01442	WASHER	2
19	SC13	NUT- NYLOCK	2
20	C01845F	LATCH	1
21	C01855F	JAW- UPPER	1
22	B01441	BUSHING- JAW	1
23	C01853F	LOWER JAW	1
24	B01435F	TRIGGER GUARD	1
25	A02073F	TRIGGER- LTWT FINISH	1
26	TR105026	TEETH- ROLL PIN FOR	3
27	C04573	PUSHER- 3/4 SC7	1

## Parts List for SC7 Type 0

Item Number	Part Number	Description	Qty Required
28	TL770204	SCREW- BUTTN HDSOC C	3
29	B04545	SHOE- MAGAZINE SC7	1
30	B1545010	MAGAZINE SHIM (.010)	1
31	AD04568	ASSEMBLY- MAGAZINE S	1
31	D04568	MAGAZINE- 3/4 PLAST	1
32	TL846206	SCREW- PH PN SHELF T	3
33	B04571	GUARD- RING SC7	1
34	B01507	BOLT- JAW (1.41 LG.	2
35	SC97A	SPRING- CONSTANT FOR	1
36	B04570	CLIP- ANTIBACKUP SC7	1
37	TL861511	PIN- ROLL 3/32 DIA X	2
38	AC04574	ASSEMBLY- 3/4 SPRIN	1
38	C04574	BRACKET- SPRING SPOO	1
39	SC100	SPRING- SHOE	2
40	AB04575	ASSEMBLY- 3/4 PUSHE	1
40	B04575	WELDMENT- FEEDR GUID	1
41	TL710216	SOCKET HEAD CAP SCRE	2
42	SC18	SCREW- BUTTON HEAD C	1
43	B01425F	STEM- THROTTLE	1
44	B03042	FRONT VALVE SEAT	1
45	SC09	O-RING H70-013	2
46	SC21	SCREW- SOCKET HEAD C	2
48	AD04579F	ASSEMBLY- HOUSING SC	1
48	C03916	GRIP- SC TOOL (Part	1
49	B03044	SPACER- THROTTLE VAL	1
50	B04587	SPRING- THROTTLE VAL	1
51	B03043	REAR VALVE SEAT	1

## Parts List for SC7 Type 0

Item Number	Part Number	Description	Qty Required
52	B01426	DEFLECTOR- AIR	1
53	B01421	SUPPORT- O-RING END	4
54	B01422	SUPPORT- O-RING CENT	2
55	B01455	WASHER- THROTTLE VAL	2
90	159919	LABEL-WARNING-MIHCN	1
800	100653	LUBE (2CC)	1
800	100679	LUBE (1LB.CAN)	1