



Parts List for ST4500-AR Type 1

Item Number	Part Number	Description	Qty Required
1	90534860	SWITCH (ON-OFF)	1
2	243805-00	BLADE	1
3	681914-00	SCREW	2
4	90506156	GUARD ASSEMBLY	1
5	244179-00	TRIGGER	1
6	000000-00	No Longer Available	1
7	598936-00	COMPRESSION SPRING	1
8	330013-04	SCREW	1
9	143684-04	SPOOL	1
10	682378-02	CAP,BUMP	1
11	682235-00	SPRING	1
12	90550447-01	FIELD	1
13	90550448-01	ARMATURE	1
14	90531225	SUPPORT BEARING	1
15	90531226	SUPPORT BEARING	1
16	574853-08	BEARING	2
17	90531224-01	BRUSH	2
18	90531223	BRUSH HOLDER	2
19	598768-00	WARNING LABEL	1
20	330019-08	SCREW	2
21	037653-00	RING, RETAINING	1
23	90531238	FLAT WASHER	2
24	833912-01	FAN	1
26	330019-04	SCREW,PLASTITE	14
27	90503998	EDGE GUIDE	1
28	243251-00	DOWEL PIN	1
29	90549935	NAME PLATE	1

Parts List for ST4500-AR Type 1

Item Number	Part Number	Description	Qty Required
30	90569077	HOUSING ASSY.	1
31	90550482	WIRING,INTERNAL	1
32	90550484	LEAD WIRE ASSY	1
33	90569078	CORD SET	1
34	320078-00	BLOCK,TERMINAL	1
35	244053-00	SPRING, TRIGGER	1
36	90534978-01	HOUSING ASSY.	1
37	90508812	LABEL	1
38	90532585	BRUSH SPRING	2
39	90554998	TUBE ASSY	1
40	821057	PAN HEAD SCREW	2
41	329301-00	CLAMP,CORD	1
42	46629-01	CONNECTOR	1