


# SX150-BHF

OIL-FREE FLOORING STAPLER  
 GRAPADORA SIN ACEITE PARA SUELOS  
 AGRAFEUSE POUR SOL ET SANS HUILE



## Parts List for SX150-BHF Type 0

Item Number	Part Number	Description	Qty Required
1	121051	SCREW-SHCS-M4X0.70X2	7
2	120996	CAP-FRAME	1
3	113337	SEAL-FRAME/CAP	1
4	160186	SEAL-TOP	1
5	160187	HOLD DOWN-HEADVALVE	1
6	101058	O-RING-1.487X.103	2
7	120989	SEAL-INSERT	1
8	120991	SPRING-HEADVALVE	1
9	120032	INSERT-HEADVALVE	1
10	120027	DIAPHRAM-HEAD VALVE	1
11	120028	SLEEVE-BT200	1
12	RG161210	O-RING-1.612X.103 NB	2
13	120061	SEAL-CHECK	1
14	S32109	RING-PISTON	1
15	173904	ASSEMBLY-PISTON/DRIV	1
16	171415	BUMPER	1
17	121025	GUIDE-DRIVER	1
18	121004	FRAME-OVERMOLD	1
19	121035	SEAL-FRAME END CAP	1
22	PW8	WASHER-PWR-.188	3
23	121052	SCREW-SHCS-M4X0.70X2	5
24	158445	COVER-TRIP	1
25	121283	NOSE	1
26	121279	PLATE-DRIVER	1
27	MHE4070-100	ELASTIC STOP NUT-M4	1
28	N86115	COMPRESSION SPRING	1
29	121029	STEM-VALVE	1

## Parts List for SX150-BHF Type 0

Item Number	Part Number	Description	Qty Required
30	MRG002514	O-RING-.098X.055	2
31	850144	O-RING-.614X.070	1
32	121005	HOUSING-VALVE	1
33	121024	SPRING-TRIP	1
34	120022	TRIP-UPPER	1
35	152118	ANGLE BLOCK-GUIDE	1
36	158595	ARM-LOWER CONTACT	1
37	158443	FOOT-ADJUSTABLE	1
38	100298	PIN-SPIRAL M3X30	1
39	158447	INSERT-NOSE	2
40	SEQ4	KIT	1
41	117397	KNOB-M6X1.0	2
42	120020	GUIDE-ARM	1
43	160189	TIP-CORE	1
44	160190	PIN-COILED-HD-M4X20	1
45	158736	SHUTTLE-PUSHER	1
46	174359	SPRING-PUSHER	1
48	159968	PIN-COILED-HD-M3X25	2
50	113579	SPRING-LATCH	1
51	116933	LATCH	1
54	119481	PUSHER	1
55	175650	ASSEMBLY-MAGAZINE-SX	1
56	MPW4	WASHER-PWN-M4	1
57	MSC4070-8	SCREW-SHCS-M4X0.70X8	2
59	116941	STOP-CORE	1
60	121036	KEY-HEXAGON 3MM	1
61	121288	LABEL-FASTENER SPEC.	1

## Parts List for SX150-BHF Type 0

Item Number	Part Number	Description	Qty Required
62	158612	LABEL-WARNING	1
63	121284	STOP-LATCH	1
64	158594	PLATE-NOSE	1
65	100387	SPRING-COMPRESSION	1
66	117398	SCREW-HHCS-M6X1.0X30	2
67	000000-00	No Longer Available	1
68	000000-00	No Longer Available	1
69	167188	BUMPER-REAR	1
70	167189	LATCH-COVER	1
71	167187	MAGAZINE	1
73	167191	ASSEMBLY-CORE	1
74	175414	ASSEMBLY-END CAP	1
800	100653	LUBE (2CC)	1
800	100679	LUBE (1LB.CAN)	1
876	SX150-RK	SX150 REPAIR KIT	1