



Parts List for TL10 Type 1

Item Number	Part Number	Description	Qty Required
1	90574783	HANDLE ASY,UPR	1
2	90560489	CORD HOLDER	2
3	90563366	HANDLE	1
6	90569226	INSULATOR	2
7	90569227	INSULATOR	2
9	330019-13	SCREW,M4X19	25
12	90563373	FRAME	1
13	90563583	GEAR BOX ASM	1
14	90571590	TANK HOLDER	1
16	90563392	SHROUD	1
17	90569324	TANK CAP	1
18	90573472	DUST PLUG	1
19	90578441	COVER	1
20	90574592	LABEL, INFO.	1
21	90574867	MOTOR HOUSING ASSY.	1
22	90572907	CIRCUIT BREAKER	1
24	90571803	CAP	1
28	243588-00	SCREW	4
29	096779-00	BOLT	8
30	90541772	ELAST STOP NUT	8
31	330016-03	WASHER,PLAIN	8
32	90564441	RETAINING CLIP	1
33	330045-05	LOCK SCREW	1
34	099361-10	WASHER	1
35	239715-06	WRAP,TIE	2
42	90566504	GEAR BOX ASM	1
43	90569273	ISOLATOR	1

Parts List for TL10 Type 1

Item Number	Part Number	Description	Qty Required
51	90574528	LABEL, WARNING	1
52	90569528	NAMEPLATE	1
53	90569523	LABEL, WARNING	1
54	90569522	LABEL, INFO.	1
55	90569521	ID LABEL	1
58	90574241	LABEL, INFO.	1
60	90574527	LABEL, WARNING	1
90	90578317	TINE ASSEMBLY	2
91	90578315	WHEEL ASSY	1
101	90574861	HOUSING ASSEM.	1
102	90534860	SWITCH (ON-OFF)	1
103	90568029	LEVER	1
104	90569995	DOWEL PIN	1
105	90572652	TORSION SPRING	1
106	90571023	CORD ASSY	1
107	90571029	LEAD WIRE	1
124	90541817	MACHINE SCREW	2
125	903693	NUT	2
141	90566499	HANDLE	1
142	90573907	LINKAGE	1
143	242488-00	WASHER	6
144	000000-00	No Longer Available	2
145	330021-02	NUT	2
160	90574866	TANK ASSEMBLY	1
164	90542737	KNOB ASSEMBLY	2
165	90557530	BOLT	2
166	90575409	CARRIAGE BOLT	4

Parts List for TL10 Type 1

Item Number	Part Number	Description	Qty Required
167	90560803	FLANGE NUT	4
169	90560897	BOLT	2
170	90563377	BAR	1
171	90570598	COTTER PIN	2
172	90563396	PIN	2
173	90563394	COTTER PIN	2