







Parts List for TS220LS Type 1

Item Number	Part Number	Description	Qty Required
1	000000-00	No Longer Available	1
1	000000-00	No Longer Available	1
2	489009-00	SLIDE	1
3	1246013	CAP SCREW	2
4	904030301757S	LOCK WASHER	2
5	488855-00	SCREW	1
6	489548-00	POINTER	1
7	1345099	HANDLE	1
8	491964-00	NUT	1
9	488997-00	ECCENTRIC CAM	1
10	488998-00	ADJUSTING SCREW	1
11	489001-00	PIN	1
12	489000-00	PIN	1
13	000000-00	No Longer Available	1
14	489003-00	SPRING	1
15	1243501	SCREW	2
16	489005-00	SPRING PLATE	1
17	489006-00	PLATE	1
18	1246140	FL WASHER	1
19	489007-00	SPRING	1
20	489008-00	REAR CLAMP	1
21	000000-00	No Longer Available	1
24	90517470	MITER GAUGE	1
40	489568-00	RAIL	1
41	900289	SCALE	1
42	901020100535	MACHINE SCREW	3
43	099389-06	WASHER	3

Parts List for TS220LS Type 1

Item Number	Part Number	Description	Qty Required
44	1345105	END PLUG	2
45	489576-00	SPACER	3
46	901020100513	MACHINE SCREW	1
47	901020100501	MACHINE SCREW	1
48	900218	TABLE	1
49	900060	TABLE INSERT	1
50	1341235	SCREW	2
50	1341235	SCREW	2
51	489081-00	RUBBER BUMPER	4
52	489082-00	FLAT HEAD SCREW	6
53	489578-00	OPEN-END WRENCH	1
54	1313197	WRENCH BOX END	1
55	1345794	JUMPER WIRE	1
56	90514149	CORDSET	1
57	1342438	SCREW	2
58	1310210	LOCKWASHER	4
59	1243569	NUT	2
60	90515441-02	BASE	1
61	489581-00	WARNING LABEL	1
62	489113-00	BASE PLATE	1
63	489110-00	RUBBER FOOT	1
64	1313229	SWITCH W/PLATE	1
65	1343360	WASHER	1
66	1313228	NUT	1
67	491429-00	SWITCH COVER	1
68	1345695	CORD CLAMP	1
69	1342444	SCREW	2

Parts List for TS220LS Type 1

Item Number	Part Number	Description	Qty Required
70	438010170206S	SWITCH	1
71	422390670001	SWITCH ACTUATOR	1
72	1343051	SCREW	1
73	000000-00	No Longer Available	1
74	489101-00	THREADED ROD	1
75	489322-00	HANDWHEEL	1
76	1342035	SCREW	1
77	491731-00	HANDLE	1
78	490375-00	SCREW	1
79	899960	LEVER	1
80	5140010-69	WASHER	1
81	904070105555S	FIBRE WSHR	1
82	905657	NAMEPLATE	1
83	1330398	SCREW	4
84	000000-00	No Longer Available	1
85	489097-00	SLEEVE	1
86	1343362	SCREW	5
87	1243569	NUT	1
88	1346725	BLOCK	1
89	1346724	SPRING CLIP	1
90	1310210	LOCKWASHER	1
91	1243501	SCREW	1
92	1341104	SCREW	1
93	1246140	FL WASHER	1
94	1343545	WASHER	4
95	1340406	SCREW	4
96	1345742	HEX HD BOLT	4

Parts List for TS220LS Type 1

Item Number	Part Number	Description	Qty Required
97	488837-00	WARNING LABEL	2
98	000000-00	No Longer Available	1
101	489118-00	RIVET	2
102	492604-00SV	GUARD ASSEMBLY	1
102	492720-00	GUARD	1
103	901010605768S	BOLT	1
104	489122-00	TOOTH WASHER	1
105	904030301757S	LOCK WASHER	1
106	904010715744	BRG WASHER	1
107	489124-00	SPLITTER BRACKET	1
108	1246015	CAP SCREW	1
109	904030301757S	LOCK WASHER	2
110	1310062	WASHER	2
111	489125-00	SPLITTER BRACKET	1
112	904030301757S	LOCK WASHER	2
113	901010600611S	CAP SCREW	2
114	489023-00	PIN	1
115	1310311	ROLL PIN	1
116	492607-00	SPLITTER	1
117	489127-00	WING NUT	1
118	489018-00	CLIP	2
119	489019-00	ANTI-KICKBACK FINGER	2
120	489022-00	SPACER	2
121	489020-00	SPACER	2
122	489021-00	SPRING	1
123	489018-00	CLIP	2
124	489026-00	HEX NUT	1

Parts List for TS220LS Type 1

Item Number	Part Number	Description	Qty Required
125	904030301757S	LOCK WASHER	1
126	489204-00	FLAT WASHER	1
127	489017-00	SUPPORT	1
128	5140081-98	SCREW	1
129	489016-00	RUBBER BUMPER	1
135	488979-00	WIRE NUT	1
136	90514148	MOTOR CORD	1
137	1345444	STRAIN RELIEF	3
138	1341235	SCREW	3
138	1341235	SCREW	3
139	490336-00	END CAP	1
140	000000-00	No Longer Available	2
141	1345704	BRUSH HOUSING	2
142	90512443	BRUSH	2
143	1349499	SCREW	3
144	488983-00	LOCK WASHER	3
145	488871-00	LOCK NUT	2
146	489591-00	MOTOR HOUSING	1
147	489141-00	WAVE WASHER	1
148	920080205352S	BEARING	1
149	489143-00	WASHER	1
150	000000-00	No Longer Available	1
151	1310210	LOCKWASHER	2
152	488855-00	SCREW	1
153	489592-00	FIELD	1
154	489593-00	ARMATURE	1
155	400081390008	BEARING	1

Parts List for TS220LS Type 1

Item Number	Part Number	Description	Qty Required
156	1345793	SCREW	2
157	488808-00	LOCK WASHER	2
158	489162-00	GEAR HOUSING	1
159	1345711	NEEDLE BEARING	1
160	492602-00	JACKSHAFT ASSEMBLY	1
161	488953-00	LOCK WASHER	3
162	1341235	SCREW	3
162	1341235	SCREW	3
166	489170-00	FLANGE	1
167	489171-00	ARBOR NUT	1
170	1349495	SCREW	3
171	1342593	PIN	1
172	901061631484	SCREW	1
173	488983-00	LOCK WASHER	1
174	489032-00	BRACKET	1
175	489175-00	STRAP	6
176	489174-00	SADDLE	1
177	489176-00	PIVOT ROD	1
178	489030-00	FLANGE NUT	6
179	489177-00	HEX FLANGE SCREW	4
180	489030-00	FLANGE NUT	1
181	489039-00	BRACKET	1
182	489035-00	SPACER	1
183	489048-00	HEX HEAD SCREW	1
184	489030-00	FLANGE NUT	1
185	1246119	ROLL PIN	1
186	489030-00	FLANGE NUT	3

Parts List for TS220LS Type 1

Item Number	Part Number	Description	Qty Required
187	904010312934S	WASHER	1
188	489190-00	BLOCK	1
189	489191-00	HEX NUT	1
190	904010317706	WASHER	1
191	489194-00	WAVE WASHER	1
192	489192-00	FIBER WASHER	1
193	000000-00	No Longer Available	1
194	489037-00	PLATE	1
195	488983-00	LOCK WASHER	1
196	901061431757S	SCREW	1
197	5140010-69	WASHER	1
198	489026-00	HEX NUT	1
199	489031-00	SPACER	1
200	489048-00	HEX HEAD SCREW	1
201	489563-00	SCREW	1
202	488983-00	LOCK WASHER	1
203	491559-00	POINTER	1
204	902010101300S	HEX NUT	1
205	491559-00	POINTER	1
206	489034-00	BRACKET	1
207	904030301656S	LOCK WASHER	1
208	489047-00	CAP SCREW	1
209	489036-00	SPACER	1
210	489033-00	MOUNTING PLATE	1
211	489027-00	SPRING PIN	1
300	492615-00	EXTENSION WING	1
301	904010315652	WASHER	3

Parts List for TS220LS Type 1

Item Number	Part Number	Description	Qty Required
302	904020101716	LOCK WASHER	3
303	901010600612S	CAP SCREW	3
304	904010315652	WASHER	1
305	904020101716	LOCK WASHER	1
306	489026-00	HEX NUT	1
307	901020100535	MACHINE SCREW	1
308	904020101716	LOCK WASHER	1
309	489576-00	SPACER	1
310	900289	SCALE	1
400	901010600611S	CAP SCREW	2
401	904010715744	BRG WASHER	2
402	1345439	REAR SUPPORT	1
403	1345438	ROD	1
404	1345437	BRACKET	4
405	488874-00	LOCK WASHER	8
406	1246014	CAP SCREW	8
407	901010600611S	CAP SCREW	2
408	5140010-69	WASHER	2
500	491964-00	NUT	4
501	491956-00	WASHER	4
502	491956-00	WASHER	4
503	489303-00	HEX HEAD SCREW	4
504	000000-00	No Longer Available	2
505	900365	BRACKET	2
506	427990480001	FOOT	4
507	1313325	SCREW	16
508	491737-00	LEG	4

Parts List for TS220LS Type 1

Item Number	Part Number	Description	Qty Required
509	900367	BRACKET	2
510	491956-00	WASHER	16
511	491964-00	NUT	16
512	491740-00	BRACKET	2
600	492615-00	EXTENSION WING	1
601	904010315652	WASHER	3
602	904020101716	LOCK WASHER	3
603	901010600612S	CAP SCREW	3
604	904010315652	WASHER	1
605	904020101716	LOCK WASHER	1
606	489026-00	HEX NUT	1
607	901020100535	MACHINE SCREW	1
608	099389-06	WASHER	1
609	489576-00	SPACER	1
610	400061320001S	SCALE	1
611	489570-00	CONNECTOR	1
612	489569-00	RAIL	1
701	489585-00	MOTOR ASSEMBLY	1
702	000000-00	No Longer Available	1
703	000000-00	No Longer Available	1
846	492612-00	HARDWARE KIT	1
856	000000-00	No Longer Available	1
856	6005818	BLADE	1