







Parts List for TS300 Type 2

Item Number	Part Number	Description	Qty Required
1	000000-00	No Longer Available	1
1	1246135	SCREW	2
1	1313226	RUBBER WASHER	2
2	1348724	REAR RAIL (LEFT)	1
3	1348722	REAR RAIL (RIGHT)	1
4	1310105	SCREW	5
4	488813-00	LOCK WASHER	5
4	1340637	WASHER	5
5	1340637	WASHER	2
5	488813-00	LOCK WASHER	2
5	491964-00	NUT	2
6	1243456	NUT	5
6	488874-00	LOCK WASHER	5
6	1310062	WASHER	5
9	000000-00	No Longer Available	2
10	1348889	CARRIAGE HEAD SCREW	5
11	000000-00	No Longer Available	1
12	000000-00	No Longer Available	1
13	000000-00	No Longer Available	1
14	902940	RAIL	1
15	1348723	TABLE	1
16	902894	EXT WING	2
17	1310105	SCREW	6
17	904020101703S	LOCK WASHER	6
17	491956-00	WASHER	6
18	902896	CABINET	1
19	491956-00	WASHER	4

Parts List for TS300 Type 2

Item Number	Part Number	Description	Qty Required
20	904020101703S	LOCK WASHER	4
21	1310105	SCREW	4
22	000000-00	No Longer Available	1
23	1313218	PIN	2
24	902900	HANDWHEEL ASSY	1
25	1313239	WASHER	1
26	902898	KNOB	1
27	000000-00	No Longer Available	1
28	1087576	SCREW	4
29	1313227	SCREW	4
30	1310162	SCREW	1
31	489105-00	SWITCH	1
32	1343758	KEY	1
33	1313230	SWITCH BOX	1
34	1313229	SWITCH W/PLATE	1
35	1313228	NUT	1
36	1313228	NUT	1
37	491958-00	LOCK WASHER	2
38	1243395	HEX NUT	2
39	1313220	CLAMP	2
40	1310162	SCREW	2
41	1313231	BUSHING	1
42	1313235	POWER CORD	1
43	1345226	MITER GAGE ASSY	1
55	1313270	PUSH NUT	2
56	1313271	PIN	1
57	1313282	GUARD ASSY.	1

Parts List for TS300 Type 2

Item Number	Part Number	Description	Qty Required
57	1313272	GUARD	1
58	1313273	PIN	1
59	1313274	BRACKET	1
60	1313275	LOCK RING	1
61	1313276	SPRING	1
62	1313277	SPLITTER	1
63	1313278	BUSHING	1
64	1313279	ANTI-KICKBACK FINGER	2
65	1310311	ROLL PIN	1
66	1246015	CAP SCREW	1
67	904030301757S	LOCK WASHER	2
68	904010101604S	STEEL WASHER	2
69	1313280	BRACKET	1
70	1243476	NUT	2
71	904010101608	STEEL WASHER	2
72	489127-00	WING NUT	1
73	1348739	END PLUG	1
74	1348740	REAR CLAMP	1
75	1348741	BUMPER	1
76	1246047	MACH SCREW	1
77	1341951	SCREW	2
78	1348742	FENCE BUMPER	2
79	1342000	SCREW	2
80	1343642	LOCK NUT	2
81	000000-00	No Longer Available	1
82	1341046	SCREW	2
83	1246140	FL WASHER	2

Parts List for TS300 Type 2

Item Number	Part Number	Description	Qty Required
84	1348744	POINTER	1
85	000000-00	No Longer Available	1
85	000000-00	No Longer Available	1
86	1330151	SCREW	2
87	1246140	FL WASHER	2
88	1348746	ECCENTRIC	1
89	1243496	NUT-STEEL	1
90	1348747	HANDLE	1
91	1348659	SCREW	1
92	000000-00	No Longer Available	1
94	1313197	WRENCH BOX END	1
95	1313232	WRENCH	1
96	902893	HARDWARE PACK	1
125	1343642	LOCK NUT	1
126	1313286	TRUNNION	1
127	1310154	SCREW	1
128	491956-00	WASHER	4
129	904020101703S	LOCK WASHER	4
130	491889-00	SCREW HEX HEAD	4
131	000000-00	No Longer Available	1
132	1313289	WASHER	1
133	1313290	PIN	1
134	1310155	SCREW	1
135	488983-00	LOCK WASHER	1
136	1340622	WASHER	1
137	1313287	POINTER	1
138	904010101606S	STEEL WASHER	1

Parts List for TS300 Type 2

Item Number	Part Number	Description	Qty Required
139	1313300	SPACER	1
140	1243496	NUT-STEEL	1
141	1313301	NUT	1
142	1313299	O-RING	1
143	1313305	SHAFT	1
144	1310310	ROLL PIN	1
145	1313302	COLLAR	1
146	1243304	SCREW	2
147	1246014	CAP SCREW	2
148	904030301757S	LOCK WASHER	2
149	1313303	BLOCK	1
150	1313304	BEARING	1
151	1313307	BLOCK	1
152	1310216	LOCKWASHER	2
153	1313308	SCREW	2
154	000000-00	No Longer Available	1
155	1313310	SPRING	1
156	1313311	SPECIAL WASHER	1
157	902900	HANDWHEEL ASSY	1
158	1313239	WASHER	1
159	902898	KNOB	1
160	1345233	GUARD SUPPORT	1
161	1345234	PLATE	1
162	488874-00	LOCK WASHER	2
163	1246128	CAP SCREW	2
164	1310310	ROLL PIN	1
165	1313295	SHAFT	1

Parts List for TS300 Type 2

Item Number	Part Number	Description	Qty Required
166	1313296	NUT	1
167	904010101620S	WASHER	1
168	1313297	LINK	2
169	1313293	BRACKET	1
169	1330682	CLAMP	1
169	1310143	SCREW	1
170	1246008	SET SCREW	2
171	1313291	PIN	2
172	904010101620S	WASHER	5
173	904020101703S	LOCK WASHER	5
174	000000-00	No Longer Available	5
175	491964-00	NUT	2
176	1313294	SEAT	1
177	902012012567	HEX NUT	1
178	000000-00	No Longer Available	1
234	906297	MOTOR - 15AMP - 1PH	1
235	488874-00	LOCK WASHER	1
236	1347226	SCREW	1
237	896270	GEAR HSG	1
238	000000-00	No Longer Available	1
239	1347291	SCREW	1
240	898896	MOTOR HOUSING	1
241	1349622	BLOCK	1
242	488871-00	LOCK NUT	1
243	488808-00	LOCK WASHER	1
244	1246102	FL.WASHER	1
245	1344026	SCREW	1

Parts List for TS300 Type 2

Item Number	Part Number	Description	Qty Required
246	1343267	WAVY WASHER	1
247	000000-00	No Longer Available	1
248	894278	FIELD	1
249	1347574	MOTOR CORD	1
250	894275	ARMATURE	1
251	894450	BEARING	1
252	400081390008	BEARING	1
253	1348267	BRUSH CAP	2
254	1348266	BRUSH	2
255	1246140	FL WASHER	1
256	1243407	RING	1
257	1341834	BEARING	1
350	491964-00	NUT	4
351	904010101606S	STEEL WASHER	4
352	1349177	SCREW	32
353	904010101606S	STEEL WASHER	4
354	1310105	SCREW	4
355	000000-00	No Longer Available	2
356	491956-00	WASHER	32
357	491964-00	NUT	32
358	000000-00	No Longer Available	2
359	902901	BRACKET	2
360	902902	BRACKET	2
361	000000-00	No Longer Available	4
362	427990480001	FOOT	4
363	000000-00	No Longer Available	1
365	904400	STAND ASSY	1