



## Parts List for TS430 Type 4

Item Number	Part Number	Description	Qty Required
1	576376-04	MOTOR ASSY.	1
2	330073-98	CORD/8 FT/18-2	1
3	000000-00	No Longer Available	1
4	000000-00	No Longer Available	1
5	823909-00	SHOE	1
6	000000-00	No Longer Available	1
7	376409-00	SCREW	2
8	845591	NUT	1
9	000000-00	No Longer Available	1
10	770235	CORD PROTECTOR	1
11	000000-00	No Longer Available	1
12	830393-00	LEAD,BOT.SWITCH	1
13	793254-00	SCREW	2
14	811057-00	PIN, GUIDE	1
15	000000-00	No Longer Available	1
16	374292-00	PIN	3
17	000000-00	No Longer Available	2
18	000000-00	No Longer Available	1
19	000000-00	No Longer Available	1
20	808548-00	SCREW	1
21	749286-00	YOKE	1
22	000000-00	No Longer Available	1
23	811055-00	GEAR	1
24	000000-00	No Longer Available	1
25	812171	SCREW	4
26	000000-00	No Longer Available	1
27	000000-00	No Longer Available	1

## Parts List for TS430 Type 4

Item Number	Part Number	Description	Qty Required
29	000000-00	No Longer Available	1
30	000000-00	No Longer Available	1
31	000000-00	No Longer Available	1
32	000000-00	No Longer Available	1
33	000000-00	No Longer Available	1
34	809961-00	SCREW	5
37	832457-00	BRUSH & HOLDER	2
38	000000-00	No Longer Available	1
39	000000-00	No Longer Available	1
43	000000-00	No Longer Available	1
44	000000-00	No Longer Available	1
45	000000-00	No Longer Available	2
46	832441-00	CONTAINER,BLADE	1
47	000000-00	No Longer Available	1
50	000000-00	No Longer Available	1
51	000000-00	No Longer Available	1
52	000000-00	No Longer Available	1
60	234900-02	PLUG 120V 2WIRE	1
800	790206-00	GREASE, 6 OZ.	1