



Model UB1103 Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty	Unit	
001	210044-4	BALL BEARING 608DDW	1	PC.	
002	681644-1	INSULATION WASHER	1	PC.	
003	513901-8	ARMATURE ASS'Y 115V	1		
	D10	INC. 1,2,4,5			
004	267237-4	FLAT WASHER 9	1	PC.	
005	211491-2	BALL BEARING 609DDW	1		
006	142292-6	FAN HOUSING COMPLETE	1		
007	266351-3	TAPPING SCREW 4X35	4	PC.	
008	267240-5	FLAT WASHER 8	1	PC.	
009	240148-8	FAN 110	1		
010	267294-2	FLAT WASHER 5	1	PC.	
011	252103-8	HEX. LOCK NUT M5-8	1	PC.	
012	345998-7	SET PLATE	1	PC.	
013	454702-4	FAN COVER	1		
014	266326-2	TAPPING SCREW 4X18	5	PC.	
015	454700-8	HANDLE COVER	1		
016	651298-8	SWITCH TG813AB-1	1	PC.	
019	266326-2	TAPPING SCREW 4X18	2	PC.	
020	687123-7	STRAIN RELIEF	1	PC.	
021	682569-2	CORD GUARD 8-85	1	PC.	
022	815D55-4	UB1103 NAME PLATE	1		
023	664064-4	POWER SUPPLY CORD AWG#18-2-2.5	1	PC.	
024	142291-8	MOTOR HOUSING COMPLETE	1		
	C10	643708-9	BRUSH HOLDER 5-11	2	PC.
025	266326-2	TAPPING SCREW 4X18	4	PC.	
026	266211-9	TAPPING SCREW 5X40	2	PC.	
027	594631-0	FIELD ASS'Y 115V	1		
	C10	654020-2	RING TERMINAL	2	PC.
	C20	654501-6	CONNECTOR P-1.25	2	PC.
028	CB303	CARBON BRUSH CB-303 (194996-6)	1	SET	
029	643755-0	HOLDER CAP	2	PC.	
A01	123245-4	NOZZLE ASS'Y	1		
	C10	454703-2	JOINT	1	
A02	123241-2	DUST BAG ASSEMBLY	1	PC.	
	C10	410602-8	FASTENER	1	PC.
E01	802H91-3	CAUTION LABEL	1		