



Parts List for WS600-AR Type 3

Item Number	Part Number	Description	Qty Required
1	5140012-54	SPOOL & LINE	1
2	5140012-55	SCREW	12
3	5140012-56	EDGE GUIDE	1
4	5140011-97	GUARD	1
5	5140012-58	HOUSING, RH	1
6	5140012-59	LOCK BUTTON	1
7	5140012-60	STOP	1
8	5140012-61	SCREW	7
9	5140011-96	SIDE HANDLE	1
10	5140012-63	TUBE ASSM.	1
11	5140012-64	HANDLE KNOB	1
12	5140012-65	BOLT	1
13	5140012-66	NUT	1
14	5140011-95	SIDE HANDLE	1
15	5140012-68	HANDLE HOUSING	1
16	5140012-69	CORD PROTECTOR	1
17	5140014-51	CORD & PLUG	1
18	5140012-71	CLAMP, CORD	1
19	5140012-72	SCREW	2
20	5140012-73	SWITCH	1
21	5140012-74	SPRING	1
22	5140012-75	TRIGGER, SWITCH	1
23	5140012-76	HANDLE HOUSING	1
24	5140012-77	SCREW	2
25	5140012-78	BLADE ASSEMBLY	1
26	5140042-75	MOTOR ASSEMBLY	1
27	5140012-80	MOTOR HOUSING	1

Parts List for WS600-AR Type 3

Item Number	Part Number	Description	Qty Required
35	5140030-45	SPOOL	1
36	5140030-46	SPOOL CAP	1
37	5140030-47	EYELET	2
38	5140030-48	ACTUATOR	1
39	5140030-49	CUTTING LINE	2
40	5140030-50	SPOOL HOUSING	1