


Ref#	Part #	Description	Qty	Context Note	Foot Note
1	199504GS	BASE			
2	B194718GS	HANDLE			
3	194886GS	ASSY, Billboard with Decal			
4	196006GS	HOSE, 25`			
5	192529GS	KIT, Pump Mounting Hardware			
6	192309GS	KIT, Hook, Base			
7	199735GS	ASSY, Pump			
	194298GS	Valve, Thermal Relief			
	23139GS	Key			
8	194264GS	KIT, Hook, Handle			
9	B2203GS	KIT, Handle Connector			
10	192310GS	KIT, Vibration Mount			
11	B3263GS	GUN			
12	21760GS	ORIFICE			
13	188792HGS	ASSY, Wand			
14	192311GS	KIT, Wheel			
	192006GS	Axle			
	192050GS	E-Ring			
900		ENGINE	C	Contact Engine Manufactur	rer
	194890GS	MANUAL, Operator`s		Not Illustrated	
	MS6847	MANUAL, Engine		Not Illustrated	
	282625	COVER, Control		Not Illustrated	
	194707GS	DECAL, Recoil		Not Illustrated	
	195015GS	KIT, Tag, Warning, Srv		Not Illustrated	



Ref #	Part #	Description	Qty	Context Note	Foot Note
19	190571GS	CAP, Oil			
28	190627GS	MANIFOLD			
45	190578GS	PIN			
62	190581GS	CAP, 1/8			
76	194298GS	THERMAL RELIEF			
77	190586GS	OIL BOTTLE		(not shown)	
А	190594GS	KIT, UNLOADER STEM		Service kits include all parts shown within the box.	
В	190632GS	KIT, WATER INLET, ALUM		Service kits include all parts shown within the box.	
С	190634GS	KIT, OUTLET, ALUM		Service kits include all parts shown within the box.	
D	193808GS	KIT, HEAD BRASS		Service kits include all parts shown within the box.	
Е	193806GS	KIT, CHECK VALVES		Service kits include all parts shown within the box.	
F	190592GS	KIT, INLET CHECK		Service kits include all parts shown within the box.	
G	190593GS	KIT, CHEMICAL INJECTION		Service kits include all parts shown within the box.	
Н	193807GS	KIT, SEAL SET		Service kits include all parts shown within the box.	
J	189971GS	KIT, CHEMICAL HOSE		Service kits include all parts shown within the box.	
K	193971GS	KIT, PIPE FITTING		Service kits include all parts shown within the box.	
L	193972GS	KIT, UNLOADER SEAT		Service kits include all parts shown within the box.	
	B2384GS	FILTER, Inlet		Not Illustrated	