



## Parts List for 110 Type 1

Item Number	Part Number	Description	Qty Required
1	450130-00SV	ARMATURE & FAN	1
2	449458-71SV	FIELD	1
3	450374-12	BRUSH & SPRING	2
5	448083-01	HOLDER,BRUSH	2
6	448084-01	CAP,BRUSH	2
7	449524-00	SWITCH,TRIGGER	1
8	330072-98	CORD/8FT/18-2SJ	1
9	330003-04	BEARING,BALL	1
10	330003-09	BEARING,BALL	1
11	448079-00	PLATE,BEARING	1
13	135514-00	CHUCK & KEY	1
15	330019-30	SCREW	4
16	N209034	GEAR CASE	1
17	700964-00	BEARING,BALL	1
18	052819-00	SCREW	2
19	330004-02	BEARING,NEEDLE	3
20	147195-00	SPINDLE	1
21	449489-00SV	GEAR&SPINDLE	1
22	449486-00SV	GEAR & PINION	1
23	135937-00	BEARING,ROLLER	1
25	449493-00	BEARING, NEEDLE	1
26	450485-00	GASKET	1
28	449483-00SV	COVER-GEAR CASE	1
29	447786-00	BAFFLE,FAN	1
30	330019-18	SCREW,PLASTITE	2
30	5140004-75	HANDLE COVER	1
31	445217-02	SLEEVE	1

## Parts List for 110 Type 1

Item Number	Part Number	Description	Qty Required
32	392275-02	FIELD CASE	1
33	5140004-75	HANDLE COVER	1
34	330019-13	SCREW,M4X19	6
35	449523-00	BUTTON, LOCK	1
36	449472-00	SUPPORT, SWITCH	1
37	86634-00	CLAMP,CORD,CURV	1
38	330019-03	SCREW	2
40	449492-02	CAP,END	1
41	99371-06	NUT	1
42	449700-00	NUT CAP	1
43	135110-00	TERMINAL	6
44	628037-00	SPADE HANDLE	1
45	382531-00	KNOB	1
46	625712-00	SIDE HANDLE	1
47	330005-01	PROTECTOR,CORD	1
48	158491-00	LEAD	1
49	448172-00	TERMINAL	2
50	449490-00	GEAR	1
51	449487-00	GEAR	1
52	32114-06	CONNECTOR	1
53	400147-00	GEAR	1
54	007027-00	KEY	1
55	99173-36	SCREW	1
56	147196-00	SPACER	1
57	000000-00	No Longer Available	1
58	000000-00	No Longer Available	1
59	447735-02	SCREW	1

## Parts List for 110 Type 1

Item Number	Part Number	Description	Qty Required
71	330034-03	CHUCK KEY	1
80	065288-01	CH KEY HOLDER	1
800	429698-00	GREASE:4 LB CAN	1
835	000000-00	No Longer Available	1