


Item	Part No.	Description
1	180300	Screw Set
2	145569	Anti-Rotation Screw
3	180558	Motor Housing Assembly
4	180150	Switch
5	180151	Trigger
6	180559	Lead Wire
7	180305	Terminal Block

Item	Part No.	Description
8	180152	Driver
9	180154	Motor
10	180155	Fan
11	180156	Power Cord

The above part numbers are for serial numbers 212008311 and greater.

BOOM & TRIMMER PARTS - RYOBI 125r



Item	Part No.	Description
1	610327	Shoulder Strap Clamp
2	145819	D-Handle
3	153523	D-Handle Hardware Assembly
4	180569	Drive Shaft Housing Assembly
5	180561	Flexible Drive Shaft
6	153597	Lower Clamp Assembly
7	180547	Guard Mounting Hardware
8	180548	Guard and Blade Assembly
9	180553	Blade Assembly
10	145569	Anti-Rotation Screw
11	180549	Gearbox Assembly
12	153619	Outer Spool and Eyelet Assembly
13	145566	Eyelet
14	610660	Retainer (10 pack)
15	610317	Spring
16	153600	Inner Reel
17	153066	Bump Head Knob Assembly
*	180117	Monofil Cutting Line (50 ft.)
*	180522	Spool and Line (40 ft.) Assembly

* not shown