



## Parts List for 1348 Type 100

Item Number	Part Number	Description	Qty Required
1	450130-00SV	ARMATURE & FAN	1
2	449458-71SV	FIELD	1
3	450374-12	BRUSH & SPRING	2
5	448083-01	HOLDER,BRUSH	2
6	448084-01	CAP,BRUSH	2
7	88324-01	SWITCH,TRIGGER	1
8	330072-98	CORD/8FT/18-2SJ	1
9	330003-04	BEARING,BALL	1
10	330003-09	BEARING,BALL	1
11	448079-00	PLATE,BEARING	1
12	016643-00	SCREW	1
13	429598-00	CHUCK & KEY	1
15	330019-30	SCREW	4
16	N209034	GEAR CASE	1
17	700964-00	BEARING,BALL	1
18	052819-00	SCREW	2
19	330004-02	BEARING,NEEDLE	3
20	450494-00	SPINDLE	1
21	449489-02	GEAR&SPINDLE	1
22	449486-02	SPINDLE & GEAR	1
23	135937-00	BEARING,ROLLER	1
25	449493-00	BEARING, NEEDLE	1
26	450485-00	GASKET	1
28	449483-00SV	COVER-GEAR CASE	1
29	447786-00	BAFFLE,FAN	1
30	330019-18	SCREW,PLASTITE	2
31	445217-02	SLEEVE	1

## Parts List for 1348 Type 100

Item Number	Part Number	Description	Qty Required
32	447799-07	CASE,FIELD	1
33	450498-08	HANDLE ASSY.	1
35	330019-13	SCREW,M4X19	8
36	015559-00	SCREW	2
37	86634-00	CLAMP,CORD,CURV	1
38	330013-03	SCREW	2
40	N063572	HOUSING & SIDE HNDL	1
41	157326-00	PIN,SPIRAL	3
42	053524-02	CLAMP	1
43	135110-00	TERMINAL	3
44	680131-01	RECEPTACLE	4
45	136086-00	TERMINAL	2
46	086319-20	SIDE HANDLE	1
47	330005-01	PROTECTOR,CORD	1
49	448172-00	TERMINAL	2
50	450492-00	GEAR	1
51	449487-00	GEAR	1
53	400147-00	GEAR	1
54	007027-00	KEY	1
55	086319-20	SIDE HANDLE	1
56	450497-00	ADAPTOR	1
57	450502-00	SPACER	1
58	046934-00	RING	2
59	330003-16	BEARING,BALL	2
60	037462-00	NEEDLE BEARING	2
61	133294-01	GEAR	1
62	133295-01	PINION	1

## Parts List for 1348 Type 100

Item Number	Part Number	Description	Qty Required
63	233304-00	NAMEPLATE-SHEET	1
64	444262-00	TERMINAL	2
65	625712-00	SIDE HANDLE	1
65	625712-00	SIDE HANDLE	1
66	98001-06	SCREW	2
68	146459-00	TERMINAL	1
70	N054799SV	HEAD ASSY	1
71	158491-00	LEAD	1
80	065288-01	CH KEY HOLDER	1
81	131296-16	CHUCK KEY	1
81	330034-03	CHUCK KEY	1
82	444402-00	WRENCH	1
800	761995-01	GREASE, 6 OZ.	1
801	283484-01	GREASE,32 OZ.	1