

POWERMATIC®

Operating Instructions and Parts Manual 22-inch Planer Models 201 and 201HH




WALTER MEIER (Manufacturing) Inc.

427 New Sanford Road
LaVergne, Tennessee 37086
Ph.: 800-274-6848
www.waltermeier.com

Part No. M-0460224
Revision G1 06/2010

Copyright © 2010 Walter Meier (Manufacturing) Inc.


Parts List: Base Assembly



Index No.	Part No.	Description	Size	Qty
1	6012068	Rubber Boot		2
2	6012069	Lead Screw		1
3	6293370	Key	5 x 5 x 10	2
4	6012070	Screw w/ Washer	M4x0.7Px8Lg / 4mmx10x0.8T	4
5	6012071	Bushing		2
6	6012072	R-Ring	RTW-68	2
7	6012073	Ball Bearing	6008-2NSE	2
8	6012074	Bearing	51105	4
9	6012066	Socket Head Cap Screw	M8 x 1.25P x 25Lg	11
10	6012075	Bracket		2
11	6012076	Sprocket		3
12	6012077	Washer	25mm	2
13	6012078	Nut	M25 x 1.5	2
14	6012079	Hex Nut	M10 x 1.5P	5
15	6012080	Flat Washer	10mm x 25 x 3T	1
16	6012081	Rocker Arm		1
17	6012082	Shaft		1
18	6012083	Flat Washer	8.5mm x 19 x 2T	2
19	6012067	Spring Washer	8.2mm x 15.4	5
20	6012084	Lead Screw		1

21	6292745	Key	5 x 5 x 16	2
22	6012085	Chain	#40 x 79pcs	1
23	6012086	Bevel Gear		1
24	6012087	Screw	M5 x 0.8P x 10Lg	4
25	6012088	Strain Relief Clip	ACC-3	4
26	6012089	Pin		4
27	6012090	Base		1
28	6012091	Screw	M6 x 1.0P x 10Lg	12
29	6012092	Cover		2
30	6012093	Special Hex Screw		4
31	6012094	Hex Nut	M16 x 2.0	4
32	6012095	Foot		4
33	6012096	Set Screw	M8 x 1.25P x 30Lg	1
34	6012097	Hex Nut	M8 x 1.25	3
35	6012098	Set Screw	M5 x 0.8P x 5Lg	2
36	6012099	Bevel Gear		1
37	6012100	S-Ring	STW-20	1
38	6012101	Ball Bearing	6204-ZZ	1
39	6012102	Support Block		1
40	6012103	Shaft		1
41	6012104	Key	8 x 7 x 18	1
42	6012105	Ball Bearing	6005-ZZ	1
43	6012106	Chain	#40 x 107pcs	1
44	6012107	Sprocket		1
45	6012052	S-Ring	STW-25	1
46	6012109	Switch Cord		1
47	6012110	Power Cord	1Ph	1
	6012267	Power Cord	3Ph	1
48	6012111	Switch	460V/3Ph	1
	6012045	Switch	230V/1Ph	1
	6012294	Switch	230V/3Ph	1
49	6012112	Switch Plate		1
50	6012113	Strain Relief Bushing	M20	1
51	6012114	Cover		1
52	6012115	Motor Cord	1Ph	1
	6012266	Motor Cord	3Ph	1
53	6012048	Socket Head Cap Screw	M10 x 1.5P x 20Lg	1
54	6012116	Washer		1
55	6012117	Belt	A56	1
56	6012118	Motor Pulley		1
57	6012108	Motor	7.5HP 1Ph 230V	1
	6012108-SC	Start Capacitor	200MFD, 250VAC	2
	6012108-RC	Run Capacitor	20µF, 450VAC	1
	6012108-RC2	Run Capacitor	35µF, 450VAC	1
	6012119	Motor	7.5HP 3Ph 230/460V	1
	2210-271	Key	8x7x40mm	1
58	6012120	Flat Washer	10.3mm x 23 x 2T	8
59	6012121	Hex Nut	M12 x 1.75	4
60	6012122	Flat Washer	13mm x 28 x 3T	4
61	6012123	Adjusting Bolt		2
62	6012124	Set Screw	M8 x 1.25P x 12Lg	5
63	6012125	Spacer		2
64	6012126	Shaft		2
65	6012127	Motor Plate		1
66	6012128	Hex Screw	M10 x 1.5P x 40Lg	4
67	6012129	Set Screw	M8 x 1.25P x 20Lg	2
68	6012130	Flat Head Screw	M6 x 1.0P x 20Lg	4
69	6012269	Terminal Cover		1
70	6012270	Screw	3/16-24NC x 1/4	1
71	6012271	Screw	M5 x 0.8P x 20L	2
72	6012272	Terminal Plate		1

Gearbox Assembly



Parts List: Gearbox Assembly

Index No.	Part No.	Description	Size	Qty
	201-100.....	Gearbox Assembly		1
1.....	6012034.....	Gearbox Body		1
2.....	6012035.....	Ball Bearing.....	6201-2NSE	6
3.....	6012036.....	S-Ring	STW-16	2
4.....	6012037.....	Gear		2
5.....	6012038.....	Ball Bearing.....	6204-2NSE	2
6.....	6012039.....	Oil Seal	TC24 x 40 x 8.....	1
7.....	6012040.....	Shaft.....		1
8.....	6293370.....	Key	5 x 5 x 10	4
9.....	6012041.....	Gear		2
10.....	6012042.....	Gasket		1
11.....	6012043.....	Pin.....		4
12.....	6012044.....	Gearbox Cover		1
13.....	6012142.....	Hex Socket Cap Screw	M10 x 1.5P x 25Lg	4
14.....	6012046.....	Pulley.....		1
15.....	6012047.....	Flat Washer.....	10mm x 25 x 3T	2
16.....	6012048.....	Socket Head Cap Screw	M10 x 1.5P x 20Lg	1
17.....	6012049.....	Socket Head Cap Screw	M8 x 1.25P x 20Lg	1
18.....	6012050.....	Sprocket		1
19.....	6292789.....	Oil Plug	PT1/4"-19UNF	2
20.....	33-1051-00-1.....	Oil Seal	TC20 x 40 x 7	1
21.....	6012051.....	Shaft.....		1
22.....	6012052.....	S-Ring	STW-25	1
23.....	6292745.....	Key	5 x 5 x 16	2
24.....	6012053.....	Shaft		1
25.....	6012054.....	Gear		1
26.....	6012055.....	Shaft		1
27.....	6012056.....	Gear		1
28.....	6012057.....	Gear Assembly		1
29.....	6012058.....	Set Screw	M5 x 0.8P x 5Lg	1
30.....	6012059.....	Spring Pin	4mm x 25Lg	1
31.....	6012060.....	Shift Fork		1
32.....	6012061.....	Lever		1
33.....	6012062.....	E-Ring	ETW-12	1
34.....	6012063.....	Shift Shaft		1
35.....	6012064.....	Eye Glass Oil Level		1
36.....	6012065.....	Spring Pin	5mm x 26Lg	1
37.....	6012066.....	Socket Head Cap Screw	M8 x 1.25P x 25Lg	3
38.....	6012067.....	Spring Washer.....	8.2mm x 15.4	4
39.....	6012082.....	Shaft		1
40.....	6012286.....	Idle Sprocket		1
41.....	6012287.....	Bracket		1
42.....	6012079.....	Hex Nut	M10 x 1.5P	1
43.....	6012288.....	Stand Off		1
44.....	6012289.....	Check Nut	M10 x 1.5P	1
45.....	6012290.....	E-Ring	ETW-7	1
46.....	6012291.....	Spring		1
47.....	6012292.....	Stand Off		1

Column Assembly





Table Assembly




Parts List: Column Assembly

Index No.	Part No.	Description	Size	Qty
1.....	6012193.....	Lifting Eye	M20 x 2.5P x 30Lg	2
2.....	6012194.....	Left Column.....		1
3.....	6012195.....	Pin.....		4
4.....	6012079.....	Hex Nut.....	M10 x 1.5P.....	1
5.....	6012080.....	Flat Washer.....	10mm x 25 x 3T.....	17
7.....	6012066.....	Socket Head Cap Screw	M8 x 1.25P x 25Lg	6
8.....	6012067.....	Spring Washer.....	8.2mm x 15.4	7
9.....	6012083.....	Flat Washer.....	8.5mm x 19 x 2T	2
10.....	6012082.....	Shaft.....		1
11.....	6012197.....	Sprocket		3
12.....	6012157.....	Spring Washer.....	10.2mm x 18.4.....	16
13.....	6012198.....	Socket Head Cap Screw	M10 x 1.5P x 40Lg	2
14.....	6012199.....	Pan Head Machine Screw	M4 x 0.7P x 10Lg.....	4
15.....	6012200.....	Spring Washer.....	4.1mm x 7.7	4
16.....	6012201.....	Flat Washer.....	4.3mm x 10 x 1T	5
17.....	6012202.....	Switch Box		2
18.....	6012203.....	Left Sidecover		1
19.....	6012091.....	Screw	M6 x 1.0P x 10Lg	16
20.....	6012204.....	Hex Nut.....	5/16"-18NC	1
21.....	6012205.....	Idler Assembly		1
22.....	6012206.....	Stand Off		2
23.....	6012207.....	Stop Switch.....		1
24.....	6012208.....	Start Switch.....		1
25.....	6012209.....	Ball Detent	6mm	1
26.....	6012210.....	Spring		1
27.....	6012211.....	Shifter Hub		1
28.....	6012212.....	Set Screw	M6 x 1.0P x 12Lg	1
29.....	6012213.....	Shaft.....		1
30.....	6012214.....	Handle		1
31.....	6012087.....	Screw	M5 x 0.8P x 10Lg	4
32.....	6012088.....	Cord Clip	ACC-3.....	4
33.....	6012156.....	Socket Head Cap Screw	M10 x 1.5P x 35Lg	14
34.....	6012215.....	Right Column		1
35.....	6012216.....	Ball Bearing.....	6004ZZ	1
36.....	6293370.....	Key	5 x 5 x 10	1
37.....	6292745.....	Key	5 x 5 x 16	1
38.....	6012217.....	Shaft		1
39.....	6012218.....	Housing		1
40.....	6012219.....	Sleeve		1
41.....	6012220.....	Socket Head Cap Screw	M6 x 1.0P x 16Lg	2
42.....	6012221.....	Rocker Arm		1
43.....	6012222.....	Right Cover		1
44.....	6012223.....	Handwheel		1
45.....	6012224.....	Lock Knob		1
46.....	6012225.....	Handwheel Swivel Assembly		1
47.....	6012226.....	Label Shifter		1
48.....	6012227.....	Rivet		6
49.....	6012228.....	Pointer		1
51.....	6012230.....	Scale		1
52.....	6012293.....	Hex Nut	M20 x 2.5	1
53.....	6012231.....	Height Adjust Label		1
54.....	6012201.....	Flat Washer	4.3 x 10 x 1T	1
55.....	6012232.....	Screw	M4 x 0.7P x 8Lg	1

Parts List: Table Assembly


Index No.	Part No.	Description	Size	Qty
1.....	6012233.....	Bracket		4
2.....	BB-6203ZZ.....	Ball Bearing.....	6203-ZZ	4
3.....	6012234.....	Roller Assembly.....		2
4.....	6012079.....	Hex Nut.....	M10 x 1.5P.....	4
5.....	6012235.....	Hex Screw	M10 x 1.5P x 30Lg.....	4
6.....	6012236.....	Hex Screw	M8 x 1.25P x 16Lg.....	2
7.....	6012237.....	Hex Screw	M6 x 1.0P x 16Lg.....	2
8.....	6012238.....	Hex Screw	M10 x 1.5P x 50Lg.....	2
9.....	6012239.....	Pointer		2
10.....	6012240.....	Plate		2
11.....	6012241.....	Plate		2
12.....	6012097.....	Hex Nut.....	M8 x 1.25P.....	9
13.....	6012242.....	Set Screw	M8 x 1.25P x 35Lg.....	6
14.....	6012243.....	Table		1
15.....	6012244.....	Table Adjusting Hub.....		2
16.....	6012245.....	Bushing.....		2
17.....	6012070.....	Screw w/Washer.....	M4 x 0.7P x 8Lg/4mm x 10 x 0.8T.....	4
18.....	6012083.....	Flat Washer.....	8.5mm x 19 x 2T.....	10
19.....	6012067.....	Spring Washer.....	8.2mm x 15.4	6
20.....	6012246.....	Socket Head Cap Screw	M8 x 1.25P x 40Lg.....	6
21.....	6012048.....	Socket Head Cap Screw	M10 x 1.5P x 20Lg.....	2
22.....	6012080.....	Flat Washer.....	10mm x 25 x 3T.....	2
23.....	6012098.....	Set Screw	M5 x 0.8P x 5Lg	6
24.....	6012247.....	Special Screw		2
25.....	6012248.....	Linking Plate		3
26.....	6012249.....	Shaft.....		1
27.....	6012250.....	E-Ring	ETW-24	1
28.....	6012251.....	Set Screw	M6 x 1.0P x 12Lg.....	1
29.....	6012252.....	Hub		1
30.....	6012213.....	Shaft.....		1
31.....	6012214.....	Handle		1
32.....	6293370.....	Key	5 x 5 x 10	3
33.....	6012253.....	Handle		1
34.....	6012254.....	Fixing Plate		1
35.....	6012255.....	Fixing Plate		1
36.....	6012256.....	Pointer		1
37.....	6012257.....	Flat Washer.....	5.3mm x 12 x 1T.....	1
38.....	6012087.....	Screw	M5 x 0.8P x 10Lg.....	1
39.....	6012258.....	Special Screw		1
40.....	6012259.....	Socket Head Cap Screw	M8 x 1.25P x 16Lg.....	4
41.....	6012260.....	Shaft.....		4
42.....	6012261.....	Cam		4
43.....	6012262.....	Transfer Rod		2
44.....	6012263.....	Spring Pin	5mm x 26L	4
45.....	6012264.....	Label		1
46.....	6012227.....	Rivet		2
47.....	6012228.....	Pointer		1
48.....	6012265.....	Name Label.....		1
49.....	6012201.....	Flat Washer.....	4.3mm x 10 x 1.0T	1
50.....	6012232.....	Screw	M4 x 0.7P x 8 Lg.....	1

Parts List: Top Cover Assembly



Index No.	Part No.	Description	Size	Qty
1.....	6012181.....	Dust Hood		1
2.....	6012091.....	Screw	M6 x 1.0P x 10Lg.....	18
3.....	6012182.....	Spring Washer.....	6.1mm x 12.3	18
4.....	6012183.....	Flat Washer.....	6.6mm x 13 x 1T.....	18
5.....	6012184.....	Upper Cover.....		1
6.....	6012066.....	Socket Head Cap Screw	M8 x 1.25P x 25Lg....	10
7.....	6012185.....	Cast Hinge Half		4
8.....	6012079.....	Nut	M10 x 1.5P.....	4
9.....	6012186.....	Socket Head Cap Screw	M10 x 1.5P x 60Lg....	2
10.....	6012187.....	Deflection Plate		1
11.....	6012188.....	Top Cover		1
12.....	6012189.....	Handle		1
13.....	6012067.....	Lock Washer	8.2mm x 15.4	6
14.....	6012097.....	Hex Nut.....	M8 x 1.25P.....	10
15.....	6012190.....	Special Screw		2
16.....	6012191.....	Cylinder		2
17.....	6012192.....	Warning Label		1
18.....	6012282.....	Screw w/ Washer.....	M6 x 1.0P x 10Lg.....	4
19.....	6012283.....	Shoulder Screw		2
20.....	6012284.....	Shoulder Screw		2
21.....	6012285.....	Check Nut	M8 x 1.25P.....	2

Cutterhead Assembly



Parts List: Cutterhead Assembly

Index No.	Part No.	Description	Size	Qty
1.....	6012131.....	Socket Head Cap Screw	M10 x 1.5P x 75Lg	2
2.....	6012080.....	Flat Washer.....	10mm x 25 x 3T	10
3.....	6012132.....	Spring		2
4.....	6012133.....	Socket Head Cap Screw	M10 x 1.5P x 50Lg	2
5.....	6012079.....	Hex Nut.....	M10 x 1.5P	8
6.....	6012134.....	Pressure Bar Casting		1
7.....	6012048.....	Socket Head Cap Screw (LH Threads).....	M10 x 1.5P x 20Lg	2
8.....	6012135.....	Washer		2
9.....	6012136.....	Sprocket		3
10.....	6012137.....	Chain (infeed roller to outfeed roller)	#40 x 60 pcs	1
11.....	6012138.....	Socket Head Cap Screw	M6 x 1.0P x 16Lg	8
12.....	6012139.....	Plate		4
13.....	6012140.....	Set Screw	M8 x 1.25P x 25Lg	4
14.....	6012097.....	Hex Nut.....	M8 x 1.25P	4
15.....	6012141.....	Bearing Housing		4
16.....	6012104.....	Key	8 x 7 x 18	1
17.....	6012143.....	Outfeed Roller		1
18.....	6012144.....	Needle Bearing.....	NA-6906	4
19.....	6012048.....	Hex Socket Cap Screw (LH Threads).....	M10 x 1.5P x 20Lg	7
20.....	6012116.....	Washer		1
21.....	6012145.....	Belt	A81	2
22.....	6012146.....	Cutterhead Pulley		1
23.....	6012147.....	Bushing		1
24.....	6012148.....	R-Ring	RTW-85	1
25.....	6012149.....	Ball Bearing.....	6209-2NSE	1
26.....	6012150.....	Set Screw	M8 x 1.25P x 10Lg	8
27.....	6012151.....	Cutterhead Casting Left		1
28.....	6012152.....	Shaft.....		2
29.....	6012153.....	Shaft.....		2
30.....	6012154.....	Cutterhead *		1
31.....	6012155.....	Ball Bearing.....	6007-2NSE	1
32.....	6012156.....	Socket Head Cap Screw	M10 x 1.5P x 35Lg	6
33.....	6012157.....	Spring Washer.....	10.2mm x 18.4.....	4
34.....	6012158.....	Cutterhead Casting Right		1
35.....	6012159.....	Screw *	M5 x 0.8P x 12Lg	12
36.....	6012160.....	Knife Gib *		4
37.....	6012161.....	Washer		8
38.....	6012162.....	Spring		4
39.....	6012163.....	Shaft.....		4
40.....	6012150.....	Set Screw	M8 x 1.25P x 10Lg	4
41.....	6012164.....	Spacer		2
42.....	6012165.....	Key	8 x 7 x 30	1
43.....	6012166.....	Infeed Shaft.....		1
44.....	6012167.....	Infeed Roller		22
45.....	6012168.....	Shaft.....		132
46.....	6012169.....	Spring		132
47.....	6012170.....	Shaft.....		2
48.....	6012098.....	Set Screw	M5 x 0.8P x 5Lg	1
49.....	6012171.....	Stock Limiter		1
50.....	6012172.....	Shaft.....		2
51.....	6012173.....	Bracket, Left Hand		1
52.....	6012174.....	Sectional Chipbreaker		10
53.....	6012175.....	Spring		10
54.....	6012176.....	Bracket, Right Hand		1
55.....	6012177.....	Spacer		72
56.....	6012178.....	Anti-Kickback Finger		62
57.....	6012179.....	Knife (set of 4) *		1

58	6012180	Gib Screw *	32
59	6012273	Spring	2
60	6012274	Chain (gearbox to outfeed roller)	#40 x 72 pcs 1
61	6012275	Shaft	1
62	6012276	Idle Sprocket	1
63	6012277	Bracket	1
64	6012278	Shaft	1
65	6012279	Check Nut	M8 x 1.25P 1
66	6012083	Flat Washer	8.5mm x 19 x 2T 1
67	6012280	Socket Head Cap Screw	M8 x 1.25P x 50Lg 1
68	6012281	Spring	1
69	6012097	Hex Nut	M8 x 1.25P 2
70	6012296	Spring *	8
71	6012295	Knife Setting Gauge (not shown) *	1
72	201-672	Retainer Ring	4
73	201-673	Retainer Ring	4
	1791225	Helical Cutterhead Assembly (index #74 thru #76) **	1
74	201HH-674	Helical Cutterhead **	1
75	1791212	Knife Insert (sold in set of 10) **	150 total
76	JWP208HH-111	Knife Insert Screw **	#10-32 x 1/2" 150
77	JJ6HH-113	Star Point Screwdriver (not shown)*	2

* Index # 30, 35, 36, 57, 58, 70, 71 are used only with the straight cutterhead on Model 201.

** Index # 74, 75, 76, 77 are used only with the helical cutterhead on Model 201HH.