



**BOSCH**

# Pn-Screwdriver - Ind.

180 WATT-SERIE | 0 607 453 433

---

## Table of Content

Spare parts list.....	2
Illustration - Type.....	5

**Spare parts list**

<b>Item</b>	<b>Part Number</b>	<b>Description</b>	
1	3 605 108 177	Motor Housing	BLUE
2	3 604 090 050	Stator	180W
3	3 604 220 104	Rotor	
5	3 605 700 107	Bearing Flange	
6	1 900 905 044	groove ball bearing	7x19x6
7	3 605 700 148	Bearing Flange	
8	1 900 905 028	groove ball bearing	7x17x5
9	3 600 700 200	Insert Pipe	
12	3 600 100 030	Shim	
26	3 606 300 163	Pinion	
27	3 600 101 047	Stop Disc	
28	3 606 334 085	Ring Gear	Ø19,5 MM
29	3 606 337 056	Planetary-Gear Carrier	
30	3 600 209 013	Spacer Ring	BLACK
31	3 606 316 093	Cylindrical Gear	Z=14
32	3 600 913 000	Needle-Roller Assembly	INA K3x5x7
33	3 603 201 000	Needle Roller	
34	3 600 700 050	Intermediate housing	
35	1 903 201 042	Needle Roller	DIN 5402-A3x11,8-G2
38	3 606 337 197	Planetary-Gear Carrier	
41	3 600 905 023	groove ball bearing	
43	3 600 100 084	Supporting Disc	
56	3 603 462 007	Fitting	
57	3 600 206 005	Sealing disk	
58	3 600 105 001	Shim washer	
60	3 600 002 006	Strainer	
61	3 603 462 000	Silencer	
62	3 600 521 002	Screening Ring	
63	3 603 201 006	Straight Pin	75 MM
64	3 603 201 002	Straight Pin	35,3 MM
65	1 900 210 112	O-Ring	15x2 MM
66	3 603 201 009	Straight Pin	
67	2 917 690 036	Half-Length Grooved Pin	ISO 8741-2x10-ST
68	3 608 750 021	Valve Cone	
69	2 917 550 088	Straight Pin	DIN 6325-3M6x32

**Spare parts list**

<b>Item</b>	<b>Part Number</b>	<b>Description</b>		
73	3 600 210 122	O-Ring	25,0x2,0 MM	BLACK
74	3 600 210 105	O-Ring	1,8x1,2 MM	
75	3 603 100 029	Straight Pin		
76	3 602 033 005	Push-Button		
77	3 604 610 016	Compression Spring		
78	3 600 210 104	O-Ring	16,0x1,0 MM	
79	3 600 313 011	Screw Plug		
80	2 912 411 407	Tapping Screw	DIN 7982-ST2,9x16-F-Z	
81	3 608 750 045	Housing		
82	3 602 000 002	Changeover Lever		
83	3 604 619 017	Compression Spring		
84	3 605 500 147	Housing Cover	BLUE	
85	3 600 921 002	Guide Piece		
87	3 601 010 010	Silencer		
88	3 603 231 007	Valve Cone		
89	3 604 619 019	Compression Spring		
95	1 601 11A 3HF	Nameplate		
96	3 601 119 136	Manufacturer's nameplate		
99	3 601 110 572	Sticker		
100	3 605 125 054	Housing		
101	3 606 445 043	Clutch Element		
102	3 603 124 022	Output Shaft		
106	3 604 610 011	Compression Spring		
107	3 604 615 004	Compression Spring		
108	3 604 610 057	Compression Spring		
109	3 604 619 020	Compression Spring	BLUE	
110	3 600 224 053	Retaining ring		
113	3 600 499 023	Clamp Bushing		
114	3 600 921 001	Plain bearing		
115	3 601 023 011	Sealing plate		
116	3 600 134 014	Setting Ring		
117	1 600 101 023	Plain Washer	0,5 MM	THICK
118	3 603 003 005	Rod		
119	3 600 190 038	Support Disc		
120	3 603 344 047	Catch Disk		

## Spare parts list

Item	Part Number	Description
124	3 600 250 004	Ring
125	3 600 202 020	Backup ring
126	3 600 224 006	Retaining ring
127	1 903 230 006	Ball DIN 5401-3,5 MM-III-ST
128	1 903 230 008	Ball 4,5 MM III DIN 5401-ST
129	1 903 230 003	Ball DIN 5401-2,5MM-III-ST
133	3 600 190 024	Washer
135	3 600 224 059	Retaining ring
136	2 600 101 513	Plain Washer
140	2 916 080 012	Locking Washer DIN 6799-9-FSt
141	3 600 400 022	Protection Sleeve
143	3 600 210 038	O-Ring 9,0x1,2 MM
144	1 903 230 002	Ball 2 MM III DIN 5401 ST
145	3 600 210 116	O-Ring
652	3 603 386 066	Hose fitting
654	3 601 923 019	Suspension Loop
657	3 607 950 027	Screwdriver
706	3 604 618 003	Compression Spring WHITE
801	3 607 031 509	Cutoff Coupling Sp Set
802	3 607 031 504	Assembly Of Service Parts
804	3 607 031 304	Assembly Of Service Parts 5 PIECE
805	3 603 201 080	Assembly Of Service Parts
868	3 608 750 042	Valve Cone
876	3 607 030 332	Assembly Of Service Parts
888	3 607 031 503	Assembly Of Service Parts

Illustration - Type - E

0 607 453 433  
Issue  
Stand | 12-10-25

Fig./Abb. 1

◆ Assemble pos. 101 and pos. 102;  
now place in pos. 127 (10 ball bearings)!  
Pos. 101 und Pos. 102 zusammenfügen;  
danach 10 Kugeln Pos. 127 einfüllen!

