


Air Locker

Model # AL83A2



No.	Description	Qty.	No.	Description	Qty.	No.	Description	Qty.	No.	Description	Qty.
01	Hex Bolt	3	26	Bumper	1	50	Safety Guide Frame	1	8	Ribbon Spring Holder	1
02	Vibrate Washer	9	93	Plunger Valve Assembly (SP-P3)	1	51	Spring Pin	1	9	Hex Bolt	2
03	Exhaust Deflector	1	27	Compression Spring	1	52	Compression Spring	1	13	Hex Bolt	1
04	Hex Bolt	4	28	O-Ring	1	94	Trigger Valve Assembly (SP-P3)	1	14	Screw Nut	1
05	Hex Bolt	1	29	Trigger Plunger	1	53	O-Ring	2	15	Screw Nut	2
06	Cylinder Head Cap	1	30	O-Ring	3	54	Trigger Valve Pusher	1	16	Bushing	1
07	Hd. Piston Valve Gasket	1	31	Trigger Valve Stem	1	55	Trigger Valve Plate	1	17	Torsion Spring	1
08	Seal	1	32	O-Ring	2	56	Trigger Valve Bushing	1	18	Hook Stop Lever	1
09	Head Valve Piston	1	33	Trigger Valve Cage	1	57	Trigger Valve Plunger	1	19	Mag. End Stopper	1
90	Piston-Driver Assembly	1	34	Plain Washer	1	30	O-Ring	1	20	Plain Washer	2
10	O-Ring	1	35	Trigger Pin Spring	1	58	Hex Bolt	2	21	Hex Bolt	1
11	Piston-Driver	1	36	Trigger Valve Pin	1	10A	Ribbon Spring Assembly	1	77	Spring Bolt	1
12	O-Ring	1	40	Compression Spring	1	10	Ribbon Spring	1	78	Hex Bolt	2
13	O-Ring	1	37	Bottom Gasket	1	11	Spring Roller Pin	1	79	Handle Grip	1
14	Cylinder	1	38	Driver Guide	1	12	Spring Roller	1	80	End Cap Gasket	1
15	O-Ring	1	39	Spring Pin	2	92	Magazine Assembly	1	81	Air Inlet End Cap	1
16	O-Ring	1	41	Safety	1	1	Mag. Front Guard Right	1	82	Vibrate Washer	3
17	Support Collar Upper	3	42	Depth Control	1	2	Screw Nut	1	83	Hex Bolt	3
18	Support Collar Lower	1	43	Compression Spring	2	3	Magazine Bracket	1			
19	Sealing Ring	1	44	Steel Ball	2	4	Magazine Body	1			
20	Compression Spring	1	45	Plain Washer	1	5	Nail Guide	1			
21	Lining Ring	1	46	Hex Bolt	1	6	Mag. Front Guard Left	1			
22	Head Cap Gasket	1	47	Safety Pushing Lever	1	7	Nail Pusher	1			
23	Air Seal	1	48	Hex Bolt	4						
24	Tool Body	1	49	Trigger Body	1						
25	O-Ring	1									