




34-740
10" MOTORIZED SAW
(FOR UNITS W/SERIAL NO 9118 AND HIGHER)



REPLACEMENT PARTS

REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION
1	1313350	Table Insert, Incl:	*	34-779	Miter Gage Assembly, Const Of:
2	1246135	(Din 963) M6 x 16mm Flat Hd Screw	51	1313240	Handknob
3	1313226	Rubber Washer	52	1313241	Special Washer
4	1243398	(Din 934) M8 Hex Nut	53	1310161	(Din 85) M4 x 18mm Pan Hd Screw
5	904-01-031-2926	5/16" Flat Washer	54	1243569	(Din 934) M4 Hex Nut
6	1313215	Extension Wing	55	1313243	Pointer
7	1342662	Spacer	56	1310055	(Din 913) M6 x 6mm Hex Soc Set Screw
8	1342663	Special Screw	57	1313245	Stop Pin
9	1342709	Rail	58	1313247	Pin
10	1342710	Adapter	59	1313244	Guide Bar
11	1310105	(Din 933) M8 x 16mm Hex Hd Screw	60	1313242	Miter Gage Body
12	904-02-010-1703	5/16" Lockwasher	61	1310055	(Din 913) M6 x 6mm Hex Soc Set Screw
13	904-01-010-1605	5/16" Flat Washer	*	1313282	Guard Assembly, Const Of:
14	1313214	Table	62	1313271	Pin
15	1342661	Front Guide Rail	63	1313272	Blade Guard
16	1342691	End Plug	64	1313270	Push Nut
17	1342660	Rear Guard Rail	65	1313273	Pin
18	1313218	Push Pin	66	1313274	Guard Bracket
19	1313219	Cover	67	1313275	Lock Ring
20	1342664	Cabinet	68	1313276	Spring
21	904-01-010-1605	5/16" Flat Washer	69	1313279	Anti-Kickback Finger
22	904-02-010-1703	5/16" Lockwasher	70	1310311	(Din 1481) M4 x 22mm Roll Pin
23	1310105	(Din 933) M8 x 16mm Hex Hd Screw	71	1313277	Splitter
24	1342671	Nameplate	72	1313278	Bushing
25	1087576	Sheet Metal Screw	73	904-03-030-1757	1/4" Ext Tooth Lockwasher
26	1310143	(Din 85) M5 x 8mm Pan Hd Screw	74	1246015	(Din 933) M6 x 20mm Hex Hd Screw
27	438-01-017-0140	Switch, Incl:	75	904-01-010-1604	1/4" Flat Washer
28	400-06-068-0002	Switch Key	76	1243476	(Din 934) M12 Hex Nut
29	1313205	Warning Label	77	904-01-010-1608	1/2" Flat Washer
30	1313229	Switch w/Plate, Incl:	78	1313280	Bracket
31	1313234	Hex Nut	79	1313281	(Din 315) M6 Wing Nut
32	1243395	(Din 934) M5 Hex Nut	*	1342673	Fence Assembly, Const Of:
33	1320101	(Din 6797A) M5 Ext Tooth Lockwasher	80	1341153	(Din 933) M8 x 12mm Hex Hd Screw
34	438-01-015-0032	Relay	81	1246157	Fence
35	1243394	(Din 84) M5 x 10mm Cheese Hd Screw	82	1342674	Rear Clamp Block
36	1342705	Clamp	83	1342675	Pin
37	1225324	Capacitor	84	1342676	Spring
38	1320101	(Din 6797A) M5 Ext Tooth Lockwasher	85	1342677	Rear Clamp Hook
39	1243395	(Din 934) M5 Hex Nut	86	1342678	Lever
40	1310143	(Din 85) M5 x 8mm Pan Hd Screw	87	1342679	Lock Rod
41	1342665	Cover Plate	88	1342680	Spring
42	1342666	Switch Box	89	1342681	Front Block
43	1243395	(Din 934) M5 Hex Nut	90	1342682	Pin
44	1313220	Cable Clamp	91	1342683	Lever
45	1310162	(Din 85) M5 x 12mm Pan Hd Screw	92	1342684	Handle
46	438-01-004-0062	Strain Relief Bushing	93	1342685	Eccentric
47	1087496	Power Cord	94	1342686	Adjusting Screw
48	1342370	Jumper Wire	95	1342687	Spring
49	438-01-007-0042	Wire Nut	96	1342688	Pointer
50	1342371	Jumper Wire	97	1342689	(Din 84) M4 x 8mm Cheese Hd Screw
			98	1340490	(Din 7980) M8 Lockwasher
			99	1246157	(Din 933) M8 x 15mm Hex Hd Screw
			100	1246078	15/16" Hex Arbor Wrench
			101	1313197	13mm Open End Wrench
			102	1342690	

* NOT SHOWN ASSEMBLED



REPLACEMENT PARTS

REF. NO.	PART NUMBER	DESCRIPTION
125	1313148	(Din 985) M6 Lock Nut
126	1313286	Trunnion Bracket
127	1310154	(Din 85) M6 x 65mm Pan Hd Screw
128	904-01-010-1605	5/16" Flat Washer
129	904-02-010-1703	5/16" Lockwasher
130	1246016	(Din 933) M8 x 25mm Hex Hd Screw
131	1313288	Trunnion
132	1313287	Pointer
133	904-03-030-1795	3/16" Ext Tooth Lockwasher
134	1310155	(Din 84) M5 x 8mm Cheese Hd Screw
135	1313223	Knob
136	1313239	Plastic Washer
137	1086491	Hand Wheel Assembly
138	1310310	(Din 1481) M3 x 18mm Roll Pin
139	904-01-010-1606	3/8" Flat Washer
140	1313300	Spacer
141	1243496	(Din 934) M10 Hex Nut
142	1313301	Tilt Nut
143	1313305	Tilt Shaft
144	1310105	(Din 933) M6 x 16mm Hex Hd Screw
145	1313299	O-Ring
146	1342611	(Din 571) M8 x 24mm Lag Hex Hd Screw
147	1246157	(Din 7980) M8 Lockwasher
148	1313302	Collar
149	1310055	(Din 913) M6 x 8mm Hex Soc Set Screw
150	1313303	Bearing Block
151	1313304	Hub Ball Bearing
152	1313307	Bearing Block
153	1313309	Special Washer
154	1313310	Spring
155	1313311	Special Washer
156	1310310	(Din 1481) M3 x 18mm Roll Pin
157	1086491	Handwheel Assembly
158	1313239	Plastic Washer
159	1313223	Knob
160	1243520	(Din 7980) M6 Lockwasher
161	1342610	(Din 571) M6 x 20mm Lag Hex Hd Screw
162	1342692	Guard Mounting Rod
163	1342693	Pivot Pin
164	1342694	Elevating Shaft
165	1313297	Elevating Link
166	1342707	Pin
167	904-01-010-1620	5/16" Flat Washer
168	1310310	(Din 1481) M3 x 18mm Roll Pin
169	1313306	(Din 7513A) M6 x 18mm Pan Hd Screw
170	904-03-030-1757	1/4" Ext Tooth Lockwasher
171	1310062	M6.4 Flat Washer
173	1342713	Motor Bracket
174	1330258	External Retaining Ring
175	1242696	Elevating Nut
176	1246128	(Din 933) M6 x 40mm Hex Hd Screw
177	904-02-020-1702	1/4" Lockwasher
178	904-01-010-1603	1/4" Flat Washer
179	1246128	(Din 933) M6 x 40mm Hex Hd Screw
180	904-02-020-1702	1/4" Lockwasher
181	904-01-010-1603	1/4" Flat Washer
182	1342697	M6 Square Nut
183	1342712	Motor
184	1313292	Arbor Flange
185	902-01-201-2567	5/8" LH Arbor Nut
*	1342699	Stand Assembly, Const Of:
212	1342700	Bracket (1 x 2 5/8 x 16 9/16")
213	1243398	(Din 934) M8 Hex Nut
214	904-01-010-1606	3/8" Flat Washer
215	1243398	(Din 934) M8 Hex Nut
216	904-01-010-1606	3/8" Flat Washer
217	1342701	Bracket (1 x 2 5/8 x 18 7/8")
218	1342702	Leg
219	1313325	M8 x 16mm Carriage Bolt
220	904-01-010-1606	3/8" Flat Washer
221	1310105	(Din 933) M8 x 16mm Hex Hd Screw
222	1342703	Bracket (1 x 2 5/8 x 19 31/32")
223	1342704	Bracket (1 x 2 5/8 x 22 1/4")
224	1342381	Foot

* NOT SHOWN ASSEMBLED

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your local service outlet.