



# Operating Instructions and Parts Manual Variable Speed Mill-Drill Machines

Models: JMD-45VSPF, JMD-45VSPFT




JMD-45VSPFT (tapping model) shown

**JET**  
427 New Sanford Road  
LaVergne, Tennessee 37086  
Ph.: 800-274-6848  
[www.jettools.com](http://www.jettools.com)

**Part No. M-351050**  
Edition 2 11/2017  
ECR 171106155622  
Copyright © 2017 JET

### 12.1.1 JMD-45VSPF, -45VSPFT Table and Base Assembly – Exploded View




## 12.1.2 JMD-45VSPF, -45VSPFT Table and Base Assembly – Parts List

<b>Index No.</b>	<b>Part No.</b>	<b>Description</b>	<b>Size</b>	<b>Qty</b>
601	JMD18-228G	Table.....	31L.....	1
602	JMD18-229	Fixed T-Block.....		2
603	JMD18-230	Stop Ring.....		2
604	TS-0207021	Hex Socket Head Cap Screw .....	1/4"-20x1/2"	2
605	JMD18-368	Ball Oiler.....	1/4"	5
606	JMD18-201	Table Handwheel.....		3
606-1	TS-0267041	Set Screw .....	1/4"-20x3/8"	3
607A	JMD18-201A	Handle Assembly (#607-1 thru 607-3).....		3
607-1	JMD18-201-1	Hex Socket Head Cap Screw (RE: JMD18-201-2) ..	3/8"-16x16.....	3
607-2	JMD18-201-2	Handle .....		3
607-3	TS-0561031	Hex Nut.....	3/8"-16	3
609	JMD18-220	Table Clutch.....		1
610	JMD18-366	Spring Pin .....	5x38L mm .....	1
611	JMD18-222	Left Flange.....		1
612	TS-0208061	Hex Socket Head Cap Screw .....	5/16"-18x1"	6
613A	JMD18-223A	Table Nut Set (#613-1 thru 616-3).....		1
613-1	JMD18-223	Table Nut .....	TM23.7-10	1
613-2	TS-1502041	Hex Socket Head Cap Screw .....	M5-0.8x16.....	1
613-3	TS-1550031	Flat Washer .....	M5.....	1
616A	JMD18-224A	Table Screw Assembly (#616-1 thru 616-6) .....		1
616-1	JMD18-224	Table Lead Screw.....		1
616-2	BB-51103	Thrust Bearing .....	51103.....	2
616-3	JMD18-226	Right Flange .....		1
616-4	JMD18-202-1	Graduated Dial .....		1
616-5	JMD18-202	Dial Clutch .....		1
616-6	JMD18-366	Spring Pin .....	5x38L mm .....	1
617	JMD18N-617	Link Screw .....		2
618	JMD18-121	Indicator Plate .....		2
619	JMD18-204-2	Rivet.....	2mm.....	4
620	JMD18-216G	Center Base.....	31L.....	1
621	JMD18-219	Anti-Dust Plate .....		1
622	JMD18-217	Anti-Dust Plate Assembly .....		1
623	JMD18-227	Gib Strip .....	31L.....	1
624	JMD18-207	Gib Strip .....	31L.....	1
625	JMD18-214	Fixed Block .....		1
626	TS-0051011	Hex Cap Screw.....	5/16"-18x1/2"	4
627	JMD18-212	Gib Strip Bolt.....		2
628	JMD18N-628	Bushing.....		4
629	JMD18-213-1	Locking Handle .....		2
630	JMD18-213	Leaf Screw .....		2
631	TS-0208061	Hex Socket Head Cap Screw .....	5/16"-18x1"	2
632	TS-0051101	Hex Socket Head Cap Screw .....	5/16"-18x2-1/4"	1
633A	JMD18-215A	ACME Nut Assembly (#633-1 thru 633-3) .....		1
635A	JMD18-205A	ACME Nut Assembly (#635-1 thru 635-6) .....		1
635-1	JMD18-205	Cross Lead Screw .....	TM23.....	1
635-2	BB-51103	Thrust Bearing .....	51103.....	2
635-3	JMD18-204	Square Flange .....		1
635-4	JMD18-202-1	Graduated Dial .....		1
635-5	JMD18-202	Dial Clutch .....		1
635-6	JMD18-366	Spring Pin .....	5x38 mm .....	1
643	TS-0208022	Hex Socket Head Cap Screw .....	5/16"-24x1/2"	2
644	JMD18N-644	Lock Washer.....	5/16"	3
645	JMD18N-645	Plug.....	PT1/4"x3/8"	1
646	365534	Angle Vise .....		1
647	365534-01	Hardware Package (2 Bolts, 2 Nuts, 2 Washers) .....		1
648	JMD45GH-648	Base.....		1
	JMD40GH-AP	Accessory Package (not shown) *		1

\* Contents of JMD40GH-AP Accessory Package:

.....JMD18-020.....	Cutter Arbor .....	1
.....JMD18-022.....	Handle .....	4
.....JMD18-039.....	Handle Rod.....	3
.....JMD18-040.....	Knob .....	3
.....JMD18-050.....	Lock Handle.....	1
.....561704 .....	Drill Chuck w/Chuck Key .....	JT6, 1/2" (13mm) .....
.....JMD18-086.....	Face Mill Cutter Assembly .....	3" (74mm) .....
.....JMD18-086A .....	Cutter Insert (Installed) .....	4
.....JMD18-021.....	Chuck Arbor (Installed).....	1
.....365534 .....	Angle Vise .....	1
.....JMD18-058.....	Handle Crank.....	1
.....JMD18-201.....	Wheel.....	3
.....TS-152704 .....	Hex Wrench.....	3mm .....
.....TS-152705 .....	Hex Wrench.....	4mm .....
.....TS-152706 .....	Hex Wrench.....	5mm .....
.....TS-0209051 .....	Hex Socket Cap Screw.....	3/8"-16x1" .....
.....TS-0680041 .....	Flat Washer .....	3/8" .....
.....365534-01 .....	Hardware Package (2 Bolts, 2 Nuts, 2 Washers) .....	1
.....JMD40GH-PW .....	Plum Wrench .....	1


12.2.1 JMD-45VSPF, -45VSPFT Column Assembly – Exploded View



## 12.2.2 JMD-45VSPF, -45VSPFT Column Assembly – Parts List

<b>Index No.</b>	<b>Part No.</b>	<b>Description</b>	<b>Size</b>	<b>Qty</b>
501	JMD45GH-501	Vertical Square Column		1
502	JMD45GH-502	Headstock Swivel Base		1
503	JMD45GH-503	Oil Cup	PT1/8"	2
504	JMD45GH-504	Adjustable Screw		2
505	JMD45GH-505	Handle		2
507	JMD45GH-507	Gib		1
508	JMD45GH-508	Bushing		2
509	JMD45GH-509	Index		1
510	JMD45GH-510	Rivet	Φ2-5L	2
511	JMD45GH-511	Anti-Dust Plate		1
512	F001216	Phillips Pan Hd Machine Screw BO	M5x10L	4
513	F001175	Phillips Pan Hd Machine Screw BO	M4x8L	3
514	JMD45GH-514	Anti-Dust Plate		1
515	JMD45GH-515	Press Board		1
517	TS-0720131	Lock Washer	5/8"	5
518	TS-0071051	Hex Cap Screw	5/8"-11x2-1/2)L	5
519	JMD45GH-519	Steel Plate		2
520	F001216	Phillips Pan Hd Machine Screw BO	M5x10L	12
524	JMD45GH-524	Bracket		1
525	BB-6003ZZ	Ball Bearing	6003ZZ	2
526	F006045	C-Retainer Ring, External	S17	1
527	JMD45GH-527	Gear Shaft		1
528	JMD45GH-528	Key, Double Rd. Head	5x5x28L mm	1
529	JMD45GH-529	Rack		1
530	JMD45GH-530	Block		1
531	JMD45GH-531	Bushing		1
532	F005671	Hex Socket Head Cap Screw	M12x85L	4
533	F006033	C-Retainer Ring, Internal	R35	1
534	JMD45GH-534	Worm Shaft		1
535	JMD45GH-535	Worm Gear		1
536	JMD45GH-536	Bearing		2
537	JMD45GH-537	Support Flange		1
538	TS-1504051	Hex Socket Head Cap Screw	M8x25L	4
539	TS-1504121	Hex Socket Head Cap Screw	M8x60L	4
540	JMD40GH-59-1	Crank		1
542	JMD18-201A	Handle Assembly		1
543	JMD45GH-543	Swivel Base Flange		1
544	JMD45GH-544	Hex Socket Flat Head Screw		1
546	TS-1504041	Hex Socket Head Cap Screw	M8x20L	1
547	TS-1540061	Hex Nut	M8	1
548	SB-6MM	Steel Ball	Ø6mm	1
550	F005461	Hex Socket Head Cap Screw	M12-1.75x75	1
552	TS-2284352	Pan Head Screw	M4x35L	2
553	JMD40GH-124	Lamp Assembly	110V	1
554	GHD20-126	Lamp Base		1
555	TS-1503031	Hex Socket Cap Screw	M6x12L	2

### 12.3.1 JMD-45VSPF, -45VSPFT Gear Head Assembly – Exploded View




### 12.3.2 JMD-45VSPF, -45VSPFT Gear Head Assembly – Parts List

<b>Index No.</b>	<b>Part No.</b>	<b>Description</b>	<b>Size</b>	<b>Qty</b>
29	TS-081C022	Phillips Pan Hd Machine Screw	3/16"-24UNCx3/8"L	4
40	GHD20PF-40	Screw	3/16" x 3/8"	1
42	61105	Spring Base		1
43	GHD20PF-43	Spring Pin	3 x 12 mm	2
44	GHD20PF-44	Screw	3/16" x 3/4"	3
45	61103S	Spring and Cover (includes #46)		1
46	61103	Spring Cover (RE:61103S)		1
47	TS-0680021	Flat Washer	1/4"	1
48	TS-0720071	Lock Washer	1/4"	1
49	6185	Lock Knob		1
50A	GHD20-50-A	Chuck Guard Assembly (#50-1 thru 50-9)		1
50-1	JMD18-125-1	Chuck Guard and Support Rod		1
50-2	JMD18-125-2	Support Rod (RE:JMD18-125-1)		1
50-3	TS-2361051	Lock Washer	M5	4
50-4	TS-1502021	Hex Socket Head Cap Screw	M5 x 10	2
50-5	GHD20-50-5	Chuck Guard Bracket		1
50-6	JMD18-125-5	Rotary Support Base		1
50-7	JMD18-125-6	Hex Socket Head Cap Screw	M5 x 15L	2
50-8	TS-1551041	Lock Washer	M6	2
50-9	6286490	Hex Socket Head Cap Screw	M6 x 15L	2
52	TS-0071141	Hex Cap Screw	5/8"-11 x 5-1/2"	2
53	GHD20-53	Oil Plug	1/4"PT	1
55	JMD45VSPF-55	Electric Box Complete (JMD-45VSPF)		1
	JMD45VSPFT-55	Electric Box Complete (JMD-45VSPFT)		1
65	JMD45VSPF-65	Sensor Bracket		1
66	TS-1531012	Phillips Pan Hd Machine Screw	M3X5L	2
68	JMD45VSPF-68	Top Cover		1
69	F009884	Socket Head Button Screw	M5X8L	4
70	2421003	Handle Rod Assembly		1
76	2401076	Scale		1
76-1	2450060	Pointer		3
78	6112	Rubber Gasket		1
82	6114	Lock Nut		1
83	GHD20PF-83	Star Washer, External Tooth	M30	1
84	BB-30206	Taper Roller Bearing	30206	1
85	6116-R8	Quill	R8	1
86	6117-R8	Spindle Shaft	R8	1
87	BB-30207	Taper Roller Bearing	30207	1
88	6119	Bearing Cap		1
89	6127	Screw Key		1
90	TS-0561031	Hex Nut	3/8"-16	1
91	2401066	Gear Lever Bracket		1
92	JMD45VSPF-92	Plug		1
93	2401068	Gear Lever (Right)		1
94	TS-0207021	Hex Socket Head Cap Screw	1/4"-20 x 1/2"	1
95	2401070	Lever Shaft (Right)		1
96	2401071	Lever Shaft (Left)		1
97	GHD20PF-97	C-Ring, External	S12	1
98	GHD20PF-98	Oil Sight Glass		1
99	GHD20PF-99	Screw	3/16" x 3/8"	8
100	GHD20PF-100	Oil Seal	G12	2
102	2401075	Speed Lever		1
106	GHD20PF-106	Oil Plug		1
107	TS-0209081	Hex Socket Head Cap Screw	3/8"-16 x 3/4"	6
108	GHD20PF-108	Miter Pin		2
109	TS-0267021	Set Screw	1/4"-20 x 1/4"	2
110	JMD45VSPF-110	Motor	1.5HP 3PH 230V	1
111	GHD20PF-111	Double Rd. Hd. Key	6 x 6 x 30mm	1
112	TS-0209031	Hex Socket Head Cap Screw	3/8"-16 x 3/4"	6

<b>Index No.</b>	<b>Part No.</b>	<b>Description</b>	<b>Size</b>	<b>Qty</b>
113 .....	GHD20-89 .....	Brass Fitting .....	.....	1
114 .....	TS-0561071 .....	Hex Nut .....	5/8"-11 .....	3
116 .....	F008242 .....	Hex Cap Screw .....	5/8"-11 x 2-1/4" .....	3
119 .....	6126-1 .....	Collar (threaded) .....	.....	1
120 .....	6125-1 .....	Collar Nut .....	.....	1
121 .....	6125-2 .....	Collar .....	.....	1
124 .....	JMD40GH-124 .....	Lamp Assembly .....	110V .....	1
125 .....	TS-2284352 .....	Phillips Pan Head Machine Screw .....	M4-0.7x35L .....	2
126 .....	GHD20-126 .....	Lamp Base .....	.....	1
127 .....	TS-1503031 .....	Hex Socket Head Cap Screw .....	M6x12L .....	2
150 .....	TS-0561071 .....	Hex Nut .....	5/8"-11 .....	2
151 .....	TS-0680081 .....	Flat Washer .....	5/8" .....	2
201 .....	2450001G .....	Head Body Cover .....	.....	1
202 .....	2450002G .....	Head Body Casting .....	.....	1
218 .....	2450008 .....	Worm Gear .....	.....	1
219 .....	TS-1523011 .....	Set Screw .....	M6 x 6 .....	4
220 .....	F006033 .....	C-Ring, Internal .....	R35 .....	4
227 .....	2450014 .....	Cover .....	.....	1
233 .....	GHD20PF-233 .....	Screw .....	M4 x 25 .....	1
235 .....	2450020 .....	Release Block .....	.....	1
236 .....	2450021 .....	Small Pinion Shaft .....	.....	1
237 .....	2450022A .....	Cylindrical Key .....	M8x12 .....	2
238 .....	2450023 .....	Worm Gear .....	.....	1
239 .....	2450024 .....	Clutch Key Base .....	.....	1
241 .....	2450026 .....	Clutch Key .....	.....	2
242 .....	2450027 .....	Spring Pin .....	Ø5x18L .....	2
243 .....	2450028 .....	Spring .....	.....	2
244 .....	GHD20PF-244 .....	C-Ring, External .....	S25 .....	1
246 .....	2450030 .....	Bushing Pin .....	.....	1
247 .....	2450031 .....	Bushing Stop .....	.....	1
248 .....	2450032 .....	Scale Base .....	.....	1
249 .....	GHD20PF-249 .....	Rivet .....	Ø2x4L .....	8
250 .....	2450033 .....	Scale Base Set Screw .....	.....	1
254 .....	2450037 .....	Handle Hub .....	.....	1
255 .....	2450038N .....	Handle Rod .....	.....	2
257 .....	2450039 .....	Handle Rod Pin .....	.....	2
258 .....	2450040 .....	Washer .....	.....	1
259 .....	TS-1504021 .....	Hex Socket Head Cap Screw .....	M8-1.25 x 12 .....	1
265 .....	GHD20PF-265 .....	Double Rd. Hd. Key .....	5 x 5 x 32mm .....	1
266 .....	2450045 .....	Cover .....	.....	1
268 .....	TS-1502031 .....	Hex Socket Head Cap Screw .....	M5-0.8 x 12 .....	2
269 .....	GHD20PF-269 .....	Key .....	4 x 4 x 10mm .....	1
270 .....	24500470 .....	Handwheel .....	.....	1
271 .....	GHD20PF-271 .....	Washer .....	.....	1
272 .....	TS-1503031 .....	Hex Socket Head Cap Screw .....	M6-1.0 x 12 .....	1
279 .....	JMD40GH-279 .....	Handle Assembly .....	5/16" .....	1
282 .....	GHD20PF-282 .....	Plug .....	7/8" .....	1
283 .....	GHD20PF-283 .....	Oil Seal .....	.....	1
287 .....	GHD20PF-287 .....	Spring Pin .....	4x16mm .....	1
291 .....	2450051 .....	Pin .....	.....	1
293 .....	HP309 .....	Taper Pin .....	M6xØ7 (1:48) .....	1
313 .....	2450063 .....	Handle .....	.....	1
315 .....	TS-0680011 .....	Flat Washer .....	3/16" .....	2
332 .....	GHD20PF-332 .....	Pin .....	Ø5x15L .....	1
333 .....	2450069 .....	Dust Plate .....	.....	1
341 .....	JMD45VSPF-341 .....	Motor Cord .....	14AWGX4C .....	1
342 .....	JMD45VSPF-342 .....	Power Cord .....	.....	1
345 .....	TS-0640081 .....	Hex Nut .....	5/16"-18 .....	1
346 .....	GHD20PF-346 .....	Manual Feed Knob .....	.....	1
347 .....	JMD45VSPF-347 .....	Name Plate for JMD-45VSPF .....	.....	1
	JET-92 .....	JET Logo (not shown) .....	92x38MM .....	1
348 .....	2450086A .....	Pinion Shaft .....	.....	1

<b>Index No.</b>	<b>Part No.</b>	<b>Description</b>	<b>Size</b>	<b>Qty</b>
349 .....	2450097 .....	Clutch Key Pin .....	Ø7x23L mm .....	2
350 .....	2450096 .....	Clutch Screw.....		1
351 .....	2450095 .....	Clutch Nut.....		1
352 .....	2450068G .....	Gear Box.....		1
353 .....	2450081A.....	Gear Shaft .....		1
354 .....	2450082A.....	Speed Change Lever.....		1
355 .....	2450083A.....	Stop .....		1
356 .....	2450084A.....	Spring Leaf .....		1
357 .....	GHD20PF-357 .....	Pin.....	Ø3x10L mm .....	2
358 .....	2450089A.....	Fixed Bushing.....		1
359 .....	2450072A.....	Gear.....		1
360 .....	2450071A.....	Gear.....		1
361 .....	2450070A.....	Gear.....		1
362 .....	2450074A.....	Washer .....		4
363 .....	2450073A.....	Shaft .....		1
364 .....	2450078A.....	Transmission Worm.....		1
365 .....	2450075A.....	Gear.....		1
366 .....	2450076A.....	Gear.....		1
367 .....	2450077A.....	Gear.....		1
368 .....	2450085A.....	Spacer Ring .....		1
369 .....	2450079 .....	Speed Lever .....		1
370 .....	GHD20PF-370 .....	Speed Scale .....		1
371 .....	290089 .....	Spring .....		1
372 .....	SB-8MM .....	Steel Ball.....	8mm.....	1
373 .....	2450087A.....	Clutch Bushing .....		1
374 .....	GHD20-374 .....	Flat Washer .....	1/2" x 7/8" x 2" .....	1
375 .....	2450100 .....	Washer .....		1
376 .....	GHD20PF-376 .....	E-Retainer Ring .....	E5 .....	2
377 .....	TS-0208071 .....	Hex Socket Head Cap Screw .....	5/16"-18 x 1-1/4"L .....	4
378 .....	CA6003ZZ .....	Ball Bearing .....		4
379 .....	GHD20PF-379 .....	Double Rd. Hd. Key .....	5 x 5 x 28L mm .....	1
380 .....	GHD20PF-380 .....	C-Ring.....		1
381 .....	2450088A.....	Graduated Bottom Plate .....		1
	LM000292 .....	ID/Warning Label, JMD-45VSPF (not shown) .....		1
	LM000293 .....	ID/Warning Label, JMD-45VSPFT (not shown) .....		1


### 12.5.1 JMD-45VSPF, -45VSPFT Gears Assembly – Exploded View



## 12.5.2 JMD-45VSPF, -45VSPFT Gears Assembly – Exploded View

<b>Index No.</b>	<b>Part No.</b>	<b>Description</b>	<b>Size</b>	<b>Qty</b>
1	JMD45VSPF-100	Main Shaft Cover		1
2	GHD20-28	Oil Seal		1
3	JMD45GH-03	Draw Bar	7/16"	1
4	GHD20-4	Retainer Ring, Internal	R68	1
5	GHD20PF-5	Retainer Ring, External	S40	1
6	BB-6008ZZ	Ball Bearing	6008ZZ	2
7	2401006	Idle Gear	53T	1
8	GHD20-7	Oil Seal		1
9	2401008	Oil Seal Ring		1
10	GHD20-9	Dust Cover		2
11	GHD20-10	C-Ring		2
12	BB-6002ZZ	Ball Bearing	6002ZZ	5
13	2401020A	Gear Shaft Assembly	15/41T	1
15	TS-1532032	Phillips Pan Hd Machine Screw	M4-0.7x10L	2
17	2401029N	Idle Gear	42T/16T	1
19	2401031	Pinion Shaft		1
22	GHD20-33	C-Ring, Ext	S18	2
23	241004A	Idle Gear	31T	1
26	GHD20-50	Oil Seal		1
27	GHD20-42	C-Ring, Internal	R62	1
28	BB-6007ZZ	Ball Bearing	6007ZZ	1
29	2401043	Pinion Shaft		1
34	241003B	Idle Gear	28T	1
36/37	GHD20-30	Steel Ball w/ Spring	5/16"	1
203	2450003	Idle Gear	33T	1
205	2450004	Transmission Worm		1
206	2450005	Idle Gear	33T	1
207	GHD20PF-207	Double Rd. Hd. Key	5x5x16	1
208	TS-1523011	Set Screw	M6x6	2
209	GHD20PF-209	C-Ring, External	S17	2
210	BB-6003ZZ	Ball Bearing	6003ZZ	1
211	GHD20PF-211	Oil Seal		1
212	BB-6001ZZ	Ball Bearing	6001ZZ	1
213	BB-6202ZZ	Ball Bearing	6202ZZ	1
214	GHD20-214	Oil Seal Cover		1
286	TS-1502031	Hex Socket Head Cap Screw	M5x12	2
292	2450052	Worm Shaft		1
293	2450053	Clutch Block		1
294	2450054	Spring		1
295	2450055	Adjustable Bolt		1
296	GHD20PF-296	Key	5x5x10	1
297	GHD20PF-297	Set Screw	M5x5	4
302	2450057	Washer		1
303	2401192	Bushing		1
351	TS-1503011	Hex Socket Head Cap Screw	M6x8L	2
352	TS-1540041	Hex Nut	M6	2

## 12.6.1 JMD-45VSPF Electric Box Assembly – Exploded View



## 12.6.2 JMD-45VSPF Electric Box Assembly – Parts List

<b>Index No.</b>	<b>Part No.</b>	<b>Description</b>	<b>Size</b>	<b>Qty</b>
	JMD45VSPF-55	Electric Box Complete (JMD-45VSPF)		1
55-1	JMD45VSPF-55-1	Electric Box		1
55-2	JMD45VSPF-55-2	Front Cover		1
55-3	JMD45VSPF-55-3	Back Plate		1
55-4	JMD45VSPF-55-4	Side Cover		1
55-5	JMD45VSPF-55-5	DRO PC Board (not shown)		1
55-6	TS-2245102	Socket Hd Button Screw	M5X10L	8
55-7	JMD45VSPF-55-7	Double Switch w/ Light		1
55-8	JMD45VSPF-55-8	VR Switch		1
55-9	JMD45VSPF-55-9	Turn Switch	NSS-22S3	1
55-11	JMD45VSPF-55-11	Emergency Switch		1
55-12	JMD45VSPF-55-12	Digital Read Out		1
55-13	TS-2283102	Phillips Pan Head Machine Screw	M3x10L	4
55-16	JMD45VSPF-55-16	Side Plate		1
55-17	JMD45VSPF-55-17	Terminal		2
55-18	TS-2171012	Phillips Pan Head Machine Screw	M4x6	2
55-19	JMD45VSPF-55-19	Inverter	RFVF-26D	1
55-20	TS-1532032	Phillips Pan Head Machine Screw	M4x10L	4
55-21	JMD45VSPF-55-21	Copper Grounding Plate		1
55-22	TS-2284082	Phillips Pan Head Machine Screw	M4x8L	8
55-23	TS-0733031	Lock Washer, Ext Tooth	#10 (M5)	4
55-24	JMD45VSPF-55-24	Relay	24V	1
55-25	JMD45VSPF-55-25	Fixed Plate		2
55-26	JMD45VSPF-55-26	Transformer		1
55-27	JMD45VSPF-55-27	Switch bracket		1
55-28	JMD45VSPF-55-28	Main Power w/ Lock Key	48x48	1
55-29	SR-PG11	Strain Relief	PG11	2
55-30	JMD45VSPF-55-30	Fan	110V	1
55-32	SR-PG8	Strain Relief	PG8	1
55-34	JMD45VSPF-55-34	Bracket		1
55-35	TS-2283102	Phillips Pan Head Machine Screw	M3x10L	2
55-36	JMD45VSPF-55-36	Sensor		1
55-37	JSH275-43-1	Phillips Pan Head Machine Screw	M3x16L	2
55-38	JMD45VSPF-55-38	Control Panel for JMD-45VSPF		1
55-39	JMD45VSPF-55-39	Fuse Bracket		1
55-40	JMD45VSPF-55-40	Fuse	0.5A 2CM	1
55-41	2SS-3C-01701	Phillips Pan Head Machine Screw	M4x40L	4
55-42	TS-1540021	Hex Nut	M4	4
55-43	JMD45VSPF-55-43	Motor Cord		1
55-46	JMD45VSPF-55-46	Power Cord	SJT 14x3C	1