


ROTARY LAWN MOWER - - MODEL NUMBER 6021P (96133001100) - PRODUCT NUMBER 961 33 00-11



ROTARY LAWN MOWER - - MODEL NUMBER 6021P (96133001100) - PRODUCT NUMBER 961 33 00-11

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532 40 29-49	Control Bar	41	532 08 86-52	Hinge Screw
2	532 19 78-08	Upper Handle (Includes Foam Grip)	42	532 40 54-21	Spring, Rear Door, LH
3	532 17 41-10	Lower Handle	43	532 40 54-23	Spring, Rear Door, RH
4	532 19 47-88	Rope Guide	44	532 18 41-93	Bolt, Rear Door
5	532 13 20-04	Locknut, Hex 1/4-20	45	532 15 04-06	Hex Head Thread Rolling Screw 3/8-16 x 1
6	532 19 15-74	Handle Bolt	46	532 40 47-63	Danger Decal
7	532 06 64-26	Wire Tie	47	532 42 65-89	Locknut, Hex 5/16-18
8	874 78 05-12	Hex Bolt 5/16-18 x 3/4	48	532 41 06-01	Axle Arm Assembly, Rear, RH
9	532 15 41-32	Hinge Bracket Assembly	49	532 41 08-15	Wheel & Tire Assembly, Rear 12 x 1-3/4
10	532 18 55-89	Mulcher Door	50	532 19 47-15	Grassbag
11	532 18 32-81	Engine Zone Control Cable	51	532 14 72-86	Hinge Rod
12	532 75 06-34	Hex Washer Head Screw #10-24 x 1/2	52	532 41 87-09	Kit, Lawn Mower Housing Assembly (Includes Key Number 46)
13	532 43 00-34	Up-Stop Bracket			
14	532 18 23-98	Handle Knob	53	532 85 10-84	Hex Head Screw 3/8-24 x 1-3/8 Grade 8
15	532 05 17-93	Hairpin Cotter	54	532 85 02-63	Helical Lockwasher
18	817 60 04-06	Screw 1/4-20 x 3/8	55	532 85 10-74	Hardened Washer
19	532 40 66-89	Axle Arm Assembly, Front, LH	56	532 40 67-12	21" Blade
20	532 40 66-90	Axle Arm Assembly, Front, RH	57	532 42 00-97	Blade Adapter
21	532 41 86-55	Kit, Rear Skirt	58	532 15 21-24	Spring, Torsion
22	532 40 64-28	Selector Spring, Front	59	- - -	Engine, Kohler, Model Number XT149-0026-EA (For engine service and replacement parts, call Kohler at 1-800-544-2444)
23	532 41 06-03	Rear Door Assembly			
25	532 41 39-24	Handle Bracket Assembly, LH	61	532 40 91-48	Nut, Hex, Flangelock
26	532 41 39-25	Handle Bracket Assembly, RH	62	873 80 04-00	Nut, Hex, Nylock 1/4-20
29	532 41 05-94	Wheel Adjusting Bracket, Front	65	532 08 83-48	Washer, Flat
30	532 40 16-29	Spacer	66	532 19 74-80	O-Ring
31	532 18 55-95	Discharge Deflector	67	532 19 79-91	Clip, Cable
32	532 41 05-95	Selector Spring, Rear	68	532 16 42-65	Grip, Foam
33	532 08 78-77	Selector Knob	73	532 40 16-30	Washer, Flat
34	532 41 06-00	Axle Arm Assembly, Rear, LH	74	532 12 50-78	Washer, Special, Engine, Zinc-Plated
35	532 75 11-53	Nut, Hex	75	532 41 36-93	Kit, Rear Baffle (Includes 3 Screws)
36	532 40 16-38	Shoulder Bolt 5/16-18	76	532 41 05-89	Baffle, Rear
37	532 41 08-31	Wheel & Tire Assembly, Front 8 x 1-3/4	77	817 41 13-12	Screw, Rear Baffle
39	532 40 91-49	Nut, Hex, Flangelock	--	532 40 47-64	Warning Decal (not shown)
40	532 41 19-49	Frame, Grassbag	--	532 43 37-73	Operator's Manual, English / French

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm. **IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.