



ORDER BY FAX OR EMAIL

f: 800-529-8680 e: spcustomer.service@itwserviceparts.com

KEY	PART NO.	DESCRIPTION
1	12266	SPALL GUARD
2	12258	BARREL EXTENSION
3	12260	BARREL EXTENSION SCREW
4	12108	BARREL ASSEMBLY
5	33657	PISTON /RING ASSEMBLY
6	33650	BREECH PLUG
7	33640	BREECH BLOCK
8	33659	SEAR SPRING
9	33642	BREECH BLOCK SPRING
10	33641	BREECH BLOCK SPRING PIN
11	12085	FIRING PIN
12	33658	FIRING PIN SPRING
13	33674	HANDLE/FIRING PIN SCREW
14	81681	RUBBER HANDLE
15	22101	HOUSING ASSEMBLY
16	33667	TRIGGER BAR
17	33647	TRIGGER SPRING
18	33668	TRIGGER BAR SPRING
19	33646	TRIGGER
20	12476	TRIGGER ROLL PIN
21	22798	STOP PIN COVER SCREW
22	22790	LOCK WASHER
23	22088	STOP PIN COVER
24	12388	STOP PIN SPRING
25	33645	STOP PIN
26	81649	SEAR
27	33671	SEAR/TRIGGER BAR ROLL PIN
30	33679	RUBBER BUMPER NOT SHOWN
—	0318R0030	DANGER LABEL, WHITE

ORDER BY FAX OR EMAIL**f: 800-529-8680 e: spcustomer.service@itwserviceparts.com**