


Air Locker

Model # AL83A



No.	Description	Qty.	No.	Description	Qty.	No.	Description	Qty.
01	Hex Bolt	3	29	Trigger Plunger	1	30	O-Ring	1
02	Vibrate Washer	9	30	O-Ring	3	58	Hex Bolt	2
03	Exhaust Deflector	1	31	Trigger Valve Stem	1	59	Magazine Front Guard	1
04	Hex Bolt	4	32	O-Ring	2	91	Ribbon Spring Assembly	1
05	Hex Bolt	1	33	Trigger Valve Cage	1	60	Spring Roller Pin	1
06	Cylinder Head Cap	1	34	Plain Washer	1	61	Spring Roller	1
07	Hd. Piston Valve Gasket	1	35	Trigger Pin Spring	1	62	Ribbon Spring	1
08	Seal	1	36	Trigger Valve Pin	1	63	Nail Pusher	1
09	Head Valve Piston	1	37	Bottom Gasket	1	92	Magazine Assembly	1
90	Piston-Driver Assembly	1	38	Driver Guide	1	64	Magazine Body	1
10	O-Ring	1	39	Spring Cylinder Pin	2	65	Hex Bolt	2
11	Piston-Driver	1	40	Compression Spring	1	66	Screw Nut	1
12	O-Ring	1	41	Safety	1	67	Plain Washer	1
13	O-Ring	1	42	Depth Control	1	68	Hook Stop Lever	1
14	Cylinder	1	43	Compression Spring	2	69	Bushing	1
15	O-Ring	1	44	Steel Ball	2	70	Torsion Spring	1
16	O-Ring	3	45	Plain Washer	2	71	Hex Bolt	1
17	Support Collar Upper	1	46	Hex Bolt	1	72	Hex Bolt	1
18	Support Collar Lower	1	47	Safety Pushing Lever	1	73	Bushing Spacer	1
19	Sealing Ring	1	48	Hex Bolt	4	74	Screw Nut	1
20	Compression Spring	1	49	Trigger Body	1	45	Plain Washer	1
21	Lining Ring	1	50	Safety Guide Frame	1	75	Magazine Bracket	1
22	Head Cap Gasket	1	51	Spring Pin	1	76	Screw Nut	2
23	Air Seal	1	52	Compression Spring	1	77	Spring Pin	1
24	Tool Body	1	94	Trigger Valve Assembly (SP-P2)	1	78	Hex Bolt	1
25	O-Ring	1	53	O-Ring	2	79	Handle Grip	1
26	Bumper	1	54	Trigger Valve Pusher	1	80	Air Inlet Cap Gasket	1
93	Plunger Valve Assembly (SP-P3)	1	55	Trigger Valve Plate	1	81	Air Inlet Cap	1
27	Compression Spring	1	56	Trigger Valve Bushing	1	82	Vibrate Washer	3
28	O-Ring	1	57	Trigger Valve Plunger	1	83	Hex Bolt	3