


CRAFTSMAN 3/8 in., 18 VOLT CORDLESS DRILL-DRIVER
 MODEL NO. 973.113070

The model number will be found on a plate attached to the motor housing. Always mention the model number in all correspondence regarding your 3/8 in. CORDLESS DRILL-DRIVER or when ordering repair parts.

SEE BACK PAGE FOR PARTS ORDERING INSTRUCTIONS



PARTS LIST

Key No.	Part Number	Description	Quan.
1	616478-003	Screw (Special)	1
2	973015-001	Chuck (Item No. 9-20988)	1
3	* Item No. 9-11103	Battery Pack (982321-001 or 982027-001)	1
4	* Item No. 9-11059	Charger (981831-002)	1
5	982113-001	Tool Bag – Not Shown	1
	972000-928	Owner's Manual	

* Can Be Purchased Thru RSOS (Retail Special Order System)