


# Makita Air Compressor Part Breakdown - MODEL AC001

Item	Description	Part #	Qty	Item	Description	Part #	Qty
1	Cylinder head	WS0101017E	1	37	Drain cock	413008-E	1
2	Bolt/cylinder head	WS0353015E	4	38	Regulator	WS0410001E	1
3	Spring washer	WS0382002E	4	39	Quick coupler	447013-E	1
4	O-Ring	WS0333011E	1	40	Unloading elbow	WS0151009E	3
5	Round-head bolt	WS0353148E	2	41	Unloading tube	WS0240024E	1
6	In & Exhaust valve plate	WS0115004E	2	42	Unloading tube	WS0240044E	2
7	In six angle bolt	WS0356005E	1	43	Unloading elbow	151001-E	3
8	Crankcase	WS0301023E	1	44	Tank foot assembly	434002-E	4
9	Crankcase front cover	WS0304019E	1	45	Flat washer	WS0381021E	4
10	Round-head bolt	WS00353021	4	46	Valve kit	WS00VK001E	1
11	Crankcase cover gasket	WS00215014	1	47	Piston kit	WS00PK001E	1
12	Electric motor/Crankcase/Wiring harness	WS2519091E	1	48	Round-head bolt	WS00353063	2
13	run capacitor	WS0462020E	1				
14	Capacitor cover	WS0455020E	1				
15	Motor fan with screw	WS0431014E	1				
16	Motor cover	WS0432013E	1				
17	Flange cross bolt	WS0354006E	3				
18	Power cord	WS0452011E	1				
19	Plastic washer	WS0384003E	4				
20	Spring washer	WS0382003E	4				
21	Round-head bolt	WS0353024E	8				
22	Air tank	WS0401184E	1				
23	Control panel	WS0488048E	1				
24	Bolt for console	365003-E	6				
25	Pressure gauge	411029-E	2				
26	Pressure gauge bolt	WS0353001E	6				
27	Set nut	WS0371001E	6				
28	Pressure switch	WS0412006E	1				
29	Strain relief clip	WS0457005E	2				
30	Check valve	WS0409017E	1				
31	Unloading elbow	WS0152101E	1				
32	Unloading tube assembly (1/4")	WSS228038E	1				
33	Unloading tube assembly (1/4")	WS0228044E	1				
34	Unloading elbow	151002-E	1				
35	rubber handle	WS0435001E	1				
36	Safety valve	WS0407009E	1				



PB-EN-MKTA-140328

www.makita.com